

5代游戏英文说明书

成品尺寸:40x60mm

数量: 3000PCS



VIDEO WALKIE-TALKIE

USER MANUAL

(Model :SWY-DJJ-01)

I. Appearance and Function Description

1-Voice changer/Back button
2-Antenna
3-Camera
4-Display screen
5-Volume Up/Up button
6-Volume Down/Down button
7-Power switch
8-MIC hole
9-Talkie button/OK button
10-Type-C interface
11-Charging indicator light
12-Lanyard hole

II. Power On/Off Function

1. The power switch is in the "OFF" position when the product leaves the factory.
2. Turn the power switch to "ON". The product will turn on automatically and a four-grid menu will appear, which includes video intercom, WeChat chat, photo taking, and gallery.
3. When using this product for the first time, please fully charge it.

Power OFF **Power ON**

III. Charging Indicator

1. Take the charging cable provided with this device and connect it to the charger. The power indicator light will turn red. When fully charged, the charging indicator light will automatically turn off.
2. Charger specifications: 5V/1A.

IV. Function Description

Basic Button Functions

1) Short press the up/down keys to move left/right and select the desired function on the main interface.
2) After selecting a function, press the OK key (call key) to enter.
3) To exit the function, press the Back key (mode key).
4) Long press the "+" key to increase the volume.
5) Long press the "-" key to decrease the volume.
6) Press and hold the " " key to conduct voice communication. The voice transmission of this device is a one-way channel. Only after the speaker finishes speaking and releases the intercom key can the other party press and hold the intercom key to send voice messages.



6) This device has the following four screen display modes. In video intercom mode, switch between them by long-pressing the volume +/- buttons.

Main menu interface: As shown in the image below

The following is a detailed explanation of the four main functions of the main menu interface:

- 1) Video intercom:
1) Press the intercom button (confirmation button) briefly to make a call; the recipient only needs to press the intercom button briefly to answer.
2) Press and hold the intercom button to initiate a call.
3) Briefly press the volume +/- to increase or decrease the volume.
4) Long-press the volume +/- to toggle video window display.
5) Press the Mode/Return key briefly to return to the main menu.
- 2) Game: Shooting, automatic bullet firing, short press volume +/- to move up/down, short press mode button to return to the main menu.
- 3) Taking Photos: Enter the photo mode by pressing the intercom/confirm button briefly to capture images, or press the mode/return button briefly to return to the main menu.
- 4) Album:
1) Enter the album interface, and briefly press the volume +/- button to view photos.
2) Press and hold the intercom/confirm button to enable the deletion option, briefly press the volume +/- to select the deletion type (all/single), then briefly press the intercom/confirm button to proceed with deletion.

3) Press and release the Mode/Back key to return to the main menu.

V. Product Power On/Off and Automatic Shutdown Function

This product enters working mode upon power-on and will remain operational regardless of use. It will automatically shut down when the battery is low. To stop use, please turn the power switch to the "OFF" position. To restart the product, simply turn the power switch to "OFF" and then to "ON" to start it normally.

VI. Product Pairing and Connection Method:

This product uses a 2.4G transmission and connection mode. Each package contains two walkie-talkies, which are already paired. These two walkie-talkies cannot be connected to other devices. If multiple sets are purchased, they can only be connected one-to-one per set; multiple products cannot be connected to each other simultaneously.

VII. Precautions:

- a. This product is suitable for outdoor use.
- b. This device is not waterproof.
- c. The indoor distance for the product should be such that the image does not stutter.

VIII. Product Specifications

Screen	2.0 Inch IPS
CMOS pixel	30W
Battery capacity	3.7V 400-650mAh
Language	English
USB Port	Type-C
Operate TEMP	-20°C~60°C
Storage TEMP	-30°C~70°C
Power	5V/1.0A
Product size	124mm*54mm*23mm

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device can be used in portable exposure conditions without restriction.

