


产品使用说明书

USER MANUAL

蓝牙音乐亚克力相框灯

Bluetooth Music Acrylic Photo Frame Lamp




蓝牙播放音乐 Bluetooth Audio	三色灯光 3 Light Modes
Type-C 供电 Type-C Powered	正面触摸控灯 Front Touch Control

本产品不设独立供电开关，连接 Type-C 电源即可使用。

No separate power switch. Connect Type-C power to use the product.

产品结构 & 功能

PRODUCT OVERVIEW



- 1 亚克力照片面板
Acrylic photo panel
- 2 底座正面触摸按钮
Front touch button
- 3 Type-C 供电接口
Type-C power input
- 4 内置蓝牙音频模块
Built-in Bluetooth audio module


重要说明 / IMPORTANT

Type-C 接口用于持续供电，并非独立开关。需要停止使用时，请断开 Type-C 电源。

The Type-C port provides continuous power and is not a power switch. Disconnect the Type-C cable to stop using the product.

灯光模式

LIGHTING MODES



使用方法 OPERATING INSTRUCTIONS

1

步骤 1：连接电源

将 Type-C 线连接至产品供电接口，再连接符合产品要求的 USB 电源适配器。接通电源后，产品即可进入工作状态。

STEP 1: CONNECT POWER

Connect the Type-C cable to the product and a suitable USB power adapter. The product is ready when powered.

2

步骤 2：切换灯光

轻触底座正面的触摸按钮，灯光将依次在冷光、暖光和冷暖光之间切换。

STEP 2: CHANGE THE LIGHT

Tap the touch button on the front of the base to cycle through Cool Light, Warm Light, and Mixed Light.

3

步骤 3：连接蓝牙

打开手机蓝牙，在可用设备列表中选择本产品进行配对。蓝牙设备名称以手机实际显示为准。

STEP 3: PAIR BLUETOOTH

Turn on Bluetooth on your phone and select the product from the available-device list. The displayed device name may vary.

4

步骤 4：播放音乐

配对成功后，在手机中播放音乐即可通过产品播放。音量、暂停和切歌建议直接在手机端控制。

STEP 4: PLAY MUSIC

After pairing, play audio on your phone. Control volume and tracks from the phone.

5

停止使用

本产品没有独立供电开关。停止使用时，请断开 Type-C 电源。

TO STOP USING

No separate power switch. Disconnect the Type-C cable when finished.

常见问题 TROUBLESHOOTING

产品不亮

No light

检查 Type-C 线与电源适配器是否连接牢固；更换可正常供电的 USB 接口或适配器；轻触正面触摸按钮。

Check the Type-C cable and adapter. Try another working USB power source, then tap the front touch button.

手机搜索不到蓝牙

Bluetooth not found

确认产品已接通电源；关闭并重新开启手机蓝牙；让产品靠近手机；断开电源后重新连接再尝试。

Make sure the product is powered. Restart phone Bluetooth, move closer, or reconnect product power.

蓝牙已连接但没有声音

Connected but no sound

确认手机媒体音量已打开；检查音频输出设备是否选择本产品；断开其他已连接的蓝牙设备。

Raise phone media volume, select this product as audio output, and disconnect other Bluetooth devices.

触摸后灯光不切换

Touch control not responding

保持手指和按钮区域干燥；轻触而非长按；断开 Type-C 电源数秒后重新连接。

Keep the button area dry, tap lightly, and reconnect Type-C power after a few seconds.

使用提示 / TIPS

- 如亚克力表面有保护膜，请在使用前撕除。 Remove any protective film before use.
- 正面触摸按钮仅用于切换灯光，不是电源开关。 The front touch button changes light only; it is not a power switch.
- 停止使用时，请断开 Type-C 电源。 Disconnect Type-C power when finished.

安全与保养 SAFETY & CARE

- 仅限室内干燥环境使用，避免进水、潮湿及高温。 For indoor use in dry areas only. Keep away from water, moisture, and heat.
- 请使用符合产品要求的电源适配器和完好的 Type-C 线。 Use a suitable power adapter and an undamaged Type-C cable.
- 请勿自行拆卸、改装或撞击产品。 Do not disassemble, modify, or strike the product.
- 清洁时先断开电源，使用柔软干布轻擦；勿使用酒精或腐蚀性清洁剂。 Disconnect power before cleaning. Wipe with a soft dry cloth; avoid alcohol or corrosive cleaners.
- 儿童使用时应由成人看护。 Adult supervision is recommended when used around children.

基本参数 BASIC SPECIFICATIONS

项目 / Item	说明 / Details
适配照片尺寸 / Photo Size	6×8 英寸 / 6×8 in
音频功能 / Audio	蓝牙播放 / Bluetooth playback
灯光模式 / Lighting	冷光、暖光、冷暖光 / Cool, Warm, Mixed
供电方式 / Power	Type-C 持续供电 / Type-C continuous power
灯光控制 / Light Control	底座正面触摸按钮 / Front touch button
独立供电开关 / Power Switch	无 / None

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.