

Network Hd Camera Manual

Please read the instructions carefully and keep them properly before use

WIFI Version

The pictures in this manual may be different from the actual product, please refer to the actual product.

Packing list

After opening the product packaging, please confirm that the equipment is intact and that the accessories are complete


Name	Specifications	Quantity
Camera host	PCS	1
manual	PCS	1
Support mounting screw pack	PCS	1
waterproof cap	PCS	1
certificate	PCS	1

Dear users:

Welcome to use our company smart camera products, no matter where you are, you can always browse the home real-time video and wonderful video through the APP, capture what you are most concerned about, get a happy life. Before using the equipment, please use the instructions carefully for smooth use.


1 APP download



1. Open the phone, scan the QR code specified below, and download and install the APP. As shown: (You can also search for "**CamHipro**" through the mobile app store)



2 WIFI mode devices for networking


AP distribution network: Please confirm whether the mobile phone is connected to the wireless network before connecting





③ Click on "Power is on, next step"



④ Click on "Not connected to the network cable"



⑤ Click on "Go add"



⑥ Scan the QR code on the fuselage (the QR code on the fuselage is the only connection sign of the camera, properly kept, do not tear up)

Note: If you scan the code, prompt "no permission", please go to the mobile phone setting application permission management, open the CamHipro software: microphone, camera, storage permission



⑧ Enter the WIFI account password and click "**Configure wireless and add**" to wait for network pairing

⑦ Click on "**Connect**"




⑩ Device status display "**online**" click to browse the screen

⑨ After the configuration is successful, the camera will emit a prompt sound, click "**confirm**" to complete the device networking



Main function introduction

5 Video camera remote operation: support the user remote mobile camera lens, remote voice intercom and other functions



Video playback and download

1. **Video playback:** Click **"video playback"** in the device list interface to enter the video playback interface




① Click the **"Video Playback"** icon on the equipment list screen to enter the video playback screen

② **"Time playback, file playback"** two modes

③ Click the Time Period where you want to play back

④ If there is no time period that you want to replay, click the **"Query"** button





⑤ Click on **"Time playback"**

⑥ Time playback You can drag the Timeline to the point in time you want to replay

⑦ Select the Date that you want to play back on



2. **Video download:** Select the video file for the required time period and

select "Download"



① Click on the "time period" that you want to download

② Select "Download"




③ Wait for the progress bar to complete

④ After downloading, you can continue to download or go to view the downloaded files

3. View local video and screenshots: click "local file" in the device list

interface to view the video and screenshots in the phone, and click the file to play directly



Use the FAQs

Question 1: How to restore the factory settings?

Answer: Please find the "reset key" button on the tail line and press it for 5-10 seconds until the prompt sound starts.

Question 2: Device prompt is offline, but the remote connection is not available, how to solve it

Answer: If the device is offline, you will first need to check whether the device power supply is normal, the network, the mobile phone can be normal Internet. If the equipment can self-test (automatic rotation) means that the power supply is normal, then check whether the route signal and name have been modified.

Question 3: How can the memory card be used correctly?

Answer: The correct way is to insert the memory card into the device and then plug in the device. You can check whether the working state of the memory card is normal through the mobile phone APP. Connect the video screen and click "set"--"SD card Settings" to view the usage and formatting of the memory card.

Product warranty regulations

Dear users:

- When the warranty service is required, please present the warranty card and the purchase invoice, and please fill in the relevant content in detail. The company will provide the quality of the user with one year from the date of purchase of the product.
- During the warranty period, the company will provide free maintenance and replacement services for the quality questions under normal use. In case of artificial damage or beyond the warranty period, the company will charge a certain fee for maintenance and replacement services.
- Man-made damage: such as improper use, damage caused by error, abnormal wear, fall, extrusion deformation, foreign body into, damp. The sealing label on the product is altered and torn and any other visible artificial damage; other cases: damage caused by unauthorized disassembly, improper operation, water intake; damage caused by force majeure: such as earthquake, flood, fire, typhoon, war; the product model code or beyond the shelf life.

Product warranty card

MAINTENANCE AND REPAIR RECORD

NAME:	TEL:
ADD:	
P.C:	PURCHASED DATE: /Y /M /D
Warranty period:From date of purchase on,one-year free warranty	

CUSTOMER DATA

DATE	CONTERTS

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.