

正面

CXZ618 Smart In-Car Companion Robot

User Manual



Life's too Plain — Spice it up!

01Basic Specifications

1. Bluetooth: Version 5.2.

2. Battery: 1500 mAh.

3. Screen: 1.85 inch.

4. Resolution: 360×360.

5. Material: Fire-Resistant ABS + Glass.

6. Surface Finish: Soft-touch UV Coating.

02Accessories List

1. Main Unit ×1

2. Magnetic Base ×1

3. Square Number Plate ×1

4. Aroma Scent Pads ×3


5. Type-C Charging Cable ×1

6. User Manual ×1

03Operation Guide

1. Take out the main unit :

Take the main unit out of the product package.



2. Power On/Off and Function Operation :



Press and hold the power key for 3 seconds:
(Power on / Power off the device)



Single-click the power key:
(Enable / Disable silent mode)



Press and hold the device screen:
(Enter the settings interface)



Swipe right on the screen:
(Return to the previous interface)

LanguageEnglish | Simplified Chinese | Traditional Chinese

Brightness1 2 3 4 5 6 7 8 9 10

Volume1 2 3 4 5 6 7 8 9 10

Expression Frequency20 30 40 50 60 90 120 150 180 sec

Auto Start-Stop


Driving Sensor

Factory ResetRestore factory settings?

About

反面


3. Install and secure the main unit:



Attach the main unit to the magnetic number plate base for fixation.

4. Bluetooth connection for music playback:

Turn on Bluetooth on your mobile phone, search for the corresponding device model to pair and connect, then you can play music.



04Charging Instructions

1. To ensure safe and efficient charging, please use a certified 5V/1A standard charger and the original charging cable included with the product. Do not use incompatible charging devices.

2. With the above compatible charging equipment, it takes approximately 3–4 hours to fully charge the device. The device can be charged normally whether powered on or off.

3. It is recommended to remove the main unit from the magnetic base and charge it indoors at home or in an office environment for stable charging and extended service life.

Charging Mode:

When the low battery prompt icon pops up on the screen, connect the Type-C charging cable to the Type-C charging port of the device to start charging.

Sleep Mode:

The device automatically enters low-power sleep mode after 2 minutes of inactivity. Press the button to wake the device.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty Card

Name		Purchase date	
Phone Number		E-Mail	
Address			
Dealer's Name (Stamped)			
Warranty Content			

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

QC PASS Qualified