

Figure 5

S/N: TY0304771, Remove Front Cover of LCD, Internal View



Figure 6

S/N: TY0304771, Remove Back Cover of LCD and OSD Function Key Control Board



Figure 7

S/N: TY0304771, Audio & OSD Function Key Control Board (Component View)




Figure 8

S/N: TY0304771, Audio & OSD Function Key Control Board (Foil View)



Figure 9
S/N: TY0304771, Frame of Internal (Back View)




Figure 10
S/N: TY0304771, Remove Metal cover of PCB, Internal View



Figure 11

S/N: TY0304771, Main Board (Component View)



Figure 12

S/N: TY0304771, Main Board (Foil View)




Figure 13

S/N: TY0304771, Power Board (Component View)




Figure 14

S/N: TY0304771, Power Board (Foil View)




Figure 15

S/N: TY0304771, Remove Metal Cover of LCD Panel, Internal View



Figure 16

S/N: TY0304771, Label of LCD Panel




Figure 17

S/N: TY0304771, LVDS Board of LCD Panel (Component View)




Figure 18

S/N: TY0304771, LVDS Board of LCD Panel (Foil View)




Figure 19
S/N: TY0304771, Internal View (Speaker)



Figure 20
General Appearance (Front View w/Chunghwa Panel)



Figure 21
General Appearance (Rear View & Side View w/Chunghwa Panel)




Figure 22
Appearance (Base w/Chunghwa Panel)




Figure 23
Appearance/Rear View (I/O Ports w/Chunghwa Panel)



Figure24
S/N: TY0304746, Remove Front Cover of LCD, Internal View



Figure25

S/N: TY0304746, Remove Back Cover of LCD and OSD Function Key Control Board



Figure 26

S/N: TY0304746, Audio & OSD Function Key Control Board (Component View)




Figure 27

S/N: TY0304746, Audio & OSD Function Key Control Board (Foil View)




Figure 28

S/N: TY0304746, Frame of Internal (Back View)




Figure 29

S/N: TY0304746, Remove Metal cover of PCB, Internal View




Figure 30

S/N: TY0304746, Main Board (Component View)




Figure 31

S/N: TY0304746, Main Board (Foil View)




Figure 32

S/N: TY0304746, Power Board (Component View)



Figure 33

S/N: TY0304746, Power Board (Foil View)



Figure 34

S/N: TY0304746, Remove Metal Cover of LCD Panel, Internal View



Figure 35
S/N: TY0304746, Label of LCD Panel



Figure 36
S/N: TY0304746, LVDS Board of LCD Panel (Component View)




Figure 37

S/N: TY0304746, LVDS Board of LCD Panel (Foil View)




Figure 38

S/N: TY0304746, Internal View (Speaker)



Figure 39
D-Sub Data Cable




Figure 40
Audio Cable

