

Figure5
Remove Front Cover of LCD, Internal View



Figure6
Speaker, Internal View



Figure7

Remove Back Cover of LCD and OSD Function Key Control Board



Figure 8

OSD Function Key Control Board (Component View)



Figure 9
OSD Function Key Control Board (Foil View)




Figure 10
Frame of Internal (Back View)



Figure 11

S/N: TY0304728, Remove Metal cover of PCB, Internal View




Figure 12

S/N: TY0304728, Remove Main Board and Power Board, Internal View



Figure 13
S/N: TY0304728, Main Board (Component View)



Figure 14
S/N: TY0304728, Main Board (Foil View)




Figure 15
S/N: TY0304728, Power Board (Component View)



Figure 16
S/N: TY0304728, Power Board (Foil View)




Figure 17

S/N: TY0304728, Remove Metal Cover of LCD Panel, Internal View




Figure 18

S/N: TY0304728, Label of LCD Panel



Figure 19

S/N: TY0304728, Remove Cover of LVDS of LCD Panel, Internal View



Figure 20

S/N: TY0304728, LVDS Board of LCD Panel (Component View)




Figure 21

S/N: TY0304728, LVDS Board of LCD Panel (Component View)




Figure 22

S/N: TY0304728, LVDS Board of LCD Panel (Foil View)




Figure 23
S/N: TY0304727, Frame of Internal



Figure 24
S/N: TY0304727, Main Board (Component View)



Figure 25
S/N: TY0304727, Main Board (Foil View)




Figure 26
S/N: TY0304727, Power Board (Component Side)



Figure 27
S/N: TY0304727, Power Board (Foil View)




Figure 28
S/N: TY0304727, Remove Metal Cover of LCD Panel, Internal View



Figure 29
S/N: TY0304727, Label of LCD Panel




Figure 30
D-Sub & DVI Signal Cable

