

## FCC ID LABEL AND LOCATION

## Host PC ID Label



## Label Location

Bottom of Host PC



FCC /IC Label Location

Contains FCC ID : A3L100BNH  
IC : 649E-100BNH