



QUICK START GUIDE




Model name: EB-U1200

Product name: Power Bank

Brand name: **SAMSUNG**





Copyright © 2018 Samsung Electronics

- Please read this guide before using the device to ensure safe and proper use.
- Images may differ in appearance from the actual product. Content is subject to change without prior notice. Visit www.samsung.com to view device information, the latest guide, and more.
- Before using the battery pack, make sure it is compatible with your mobile device.
- Your consumer rights are governed by the law of the country in which you purchased the product. Please contact your service provider for more information.

Device layout

a	USB charger port	d	Wireless charging surface
b	Charger port (Type-C)	e	Charging coil
c	Indicator light	f	Battery level button

English

Charging the battery

Before using the battery pack for the first time, you must charge the battery.

Connect the battery pack to a charger.



Use only Samsung-approved chargers.



- You can charge the battery pack using the charger (sold separately).
- Depending on the type of charger you are using, you may need to use the Micro USB connector.
- The actual capacity (Wh) is measured based on the battery's output current and voltage. It may differ from the capacity (Wh) indicated on the device, depending on the output power condition, the connected device's circuit configuration, and the operation environment.
- The charger should remain close to the electric socket and easily accessible while charging.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- When the charger is correctly connected to the battery pack, the indicator light flashes red, green, and yellow, and then turns off.

Checking the remaining battery power

Check the remaining battery power by pressing the Battery level button.

The indicator lights alerts you to the remaining battery power.

Remaining battery power	Indicator light status
70–100 %	Four indicator lights on
40–70 %	Three indicator lights on
20–40 %	Two indicator lights on
5–20 %	One indicator light on
0–5 %	One indicator light blinking

Using the battery pack

Cable charging

1. Connect one end of the USB cable to the battery pack's USB charger port. Then, plug the other end of the USB cable into the mobile device's multipurpose jack.
2. After the mobile device is fully charged, disconnect the USB cable from both devices.



Depending on your mobile device's multipurpose jack, you may need to use the Micro USB connector.



Wireless charging

1. Place a supported mobile device on the wireless charging surface. **(1)**
Charging will begin when the charging coil comes into contact with the wireless charging coil of the mobile device.



Check the charging icon displayed on the screen of the mobile device for the charging status.

2. When the mobile device is fully charged, remove the mobile device from the battery pack.




Do not place the mobile device on the battery pack when conductive materials, such as metal objects, magnets, credit card, transportation card or a key card are placed between the mobile device and the battery pack. The mobile device may not charge properly or may overheat, or the mobile device or the cards may be damaged.



- Wireless charging covers are sold separately.
- The charging time may vary depending on the charging conditions.
- The battery pack supports fast charging feature. To use fast charging on the battery pack, connect it to your mobile device that supports fast charging.





Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

Use manufacturer-approved batteries, chargers, accessories, and supplies

Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

The device can be used in locations with an ambient temperature of 0 °C to 35 °C. You can store the device at an ambient temperature of -20 °C to 50 °C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan

Prevent the multipurpose jack and the small end of the charger from coming into contact with conductive materials, such as liquids, dust, metal powders, and pencil leads

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields



Correct disposal



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste.

This product is RoHS compliant.



This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste.

For information on Samsung's environmental commitments and product-specific regulatory obligations, e.g. REACH, WEEE, Batteries, visit samsung.com/uk/aboutsamsung/samsungelectronics/corporatecitizenship/data_corner.html

Declaration of Conformity

Samsung Electronics declares that this device complies with the essential requirements and relevant provisions of Directive 2014/53/EU.

Go to www.samsung.com/mobile_doc to view the Declaration of Conformity.

Band and mode

Band and mode

Wireless Charging
110.5 kHz–205 kHz

FCC Warning

a、 § 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

b、 § 15.21 Changes or modification warning.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

c、 § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- } -Reorient or relocate the receiving antenna.
- } -Increase the separation between the equipment and receiver.
- } -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- } -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

(1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et exploité avec une distance minimale de 20cm entre le radiateur et votre corps.