




English

Copyright © 2020 Samsung Electronics America, Inc.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.

Other marks are the property of their respective owners.

- Please read this guide before using the device to ensure safe and proper use.
- Before using the S Pen, make sure it is compatible with your device.
- Your consumer rights are governed by the law of the country in which you purchased the product. Please contact your service provider for more information.



Device layout

a	S Pen button	b	S Pen nib
----------	--------------	----------	-----------

Using the S Pen

Use the S Pen to perform touch actions or draw on the screen of your mobile device. You can use additional features by pressing the S Pen button (**a**).

When you attach the S Pen on the rear of your mobile device, charging will start.

Refer to the mobile device's user manual for more information.

Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

Use only charging devices and batteries approved by Samsung. Samsung accessories are designed for your device to maximize battery life. Using other accessories may invalidate your warranty and may cause damage

Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

FCC 15.21 Warning against unauthorized change

Pursuant to Part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Depending on the region or model, some devices are required to receive approval from the Federal Communications Commission (FCC). If your device is approved by the FCC, you can view the FCC ID of the device. To view the FCC ID, launch the **Settings** app and tap **About phone** → **Status**.

Samsung Mobile Products and Recycling

Samsung cares for the environment and encourages its customers to properly dispose of Devices and Samsung accessories in accordance with local regulations. In some areas, disposal of these items in household or business trash may be prohibited. Dispose of other unwanted electronics through an approved recycler. To find the nearest recycling location, go to our website: www.samsung.com/recyclingdirect or call 1-877-278-0799.

Samsung Electronics America, Inc

85 Challenger Road,
Ridgefield Park, New Jersey, 07660
Phone: 1-800-SAMSUNG (726-7864)

QUICK START GUIDE


EJ-PT870
S Pen



QUICK START GUIDE

EJ-PT870

English



Copyright © 2020 Samsung Electronics
Bluetooth® is a registered trademark of
Bluetooth SIG, Inc. worldwide.

- Please read this guide before using the device to ensure safe and proper use.
- Before using the S Pen, make sure it is compatible with your device.
- Your consumer rights are governed by the law of the country in which you purchased the product. Please contact your service provider for more information.

Device layout

a	S Pen button	b	S Pen nib
----------	--------------	----------	-----------

Using the S Pen

Use the S Pen to perform touch actions or draw on the screen of your mobile device. You can use additional features by pressing the S Pen button. When you attach the S Pen on the rear of your mobile device, charging will start. Refer to the mobile device's user manual for more information.

Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

Use manufacturer-approved batteries, chargers, accessories, and supplies

Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

FCC 15.21 Warning against unauthorized change

Pursuant to Part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Depending on the region or model, some devices are required to receive approval from the Federal Communications Commission (FCC). If your device is approved by the FCC, you can view the FCC ID of the device. To view the FCC ID, launch the **Settings** app and tap **About phone** → **Status**.

RSS-Gen, Section 8.4 Statement IC Notice

This device complies with Industry Canada licence exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
 2. This device must accept any interference, including interference that may cause undesired operation of the device.
- Depending on the region or model, some devices are required to receive approval from Innovation, Science and Economic Development Canada (ISED)/the Federal Communications Commission (FCC). If your device is approved by the ISED/FCC, you can view the ISED/FCC ID of the device. To view the ISED/FCC ID, launch the **Settings** app and tap **About phone** → **Status**.

Printed in Korea

A00000 Rev.1.0

CANADA Type 06/2020

SAMSUNG




GUIDE DE DÉMARRAGE RAPIDE

EJ-PT870

SAMSUNG

Français (Canada)



© Samsung Electronics, 2020.

Bluetooth® est une marque déposée de Bluetooth SIG, Inc. partout dans le monde.

- Veuillez lire le présent guide avant d'utiliser l'appareil afin de vous assurer d'en faire une utilisation sécuritaire et adéquate.
- Avant d'utiliser le S Pen, assurez-vous qu'il est compatible avec votre appareil.
- Vos droits en tant que consommateur sont régis par les lois du pays où vous avez acheté le produit. Veuillez communiquer avec votre fournisseur de services pour obtenir de plus amples renseignements.

Présentation de l'appareil

a	Bouton du S Pen	b	Pointe du S Pen
----------	-----------------	----------	-----------------

Utilisation du S Pen

Utilisez le S Pen pour toucher l'écran tactile ou pour dessiner sur l'écran de votre appareil mobile. Vous pouvez utiliser d'autres fonctionnalités en appuyant sur le bouton S Pen.

Lorsque vous fixez le S Pen dans l'emplacement du S Pen de votre appareil mobile, le chargement commencera.

Reportez-vous au guide d'utilisation de l'appareil mobile pour plus de détails à ce sujet.

Consignes de sécurité

Lisez toutes les consignes de sécurité avant d'utiliser l'appareil pour vous assurer d'en faire une utilisation adéquate et sécuritaire. Pour consulter toutes les consignes de sécurité, reportez-vous au site Web de Samsung.

Utilisez des piles, des chargeurs, des accessoires et des fournitures approuvés par le fabricant.

Ne touchez pas l'appareil avec les mains mouillées.

Ne laissez pas tomber l'appareil ou le chargeur et ne les exposez pas à des chocs.

Ne laissez pas des enfants ou des animaux mâcher ou sucer l'appareil.

Ne démontez pas, ne modifiez pas et ne réparez pas vous-même votre appareil.

Énoncé CNR-Gen, section 8.4 Avis IC

Cet appareil est conforme aux normes CNR d'Industrie Canada pour l'équipement exempt de licence. Son utilisation est assujettie aux deux conditions suivantes :

1. Cet appareil ne doit causer aucune interférence.
2. Cet appareil doit accepter toutes les interférences reçues, y compris celles qui pourraient provoquer un fonctionnement non souhaitable de l'appareil.

- Selon la région ou le modèle, certains appareils doivent recevoir une certification de Innovation, Sciences et Développement économique Canada (ISDE) et de la Commission fédérale des communications (FCC). Si votre appareil est approuvé par ISDE/FCC, vous pouvez trouver l'ID ISDE/FCC de l'appareil. Pour ce faire, ouvrez l'appli **Paramètres** et touchez **À propos du téléphone** → **État**.