

QUICK START GUIDE

EP-PG920A



SAMSUNG

Printed in Korea
GH68-44067A Rev.1.0
SEA Type 04/2015



Copyright © 2015 Samsung Electronics

English

- Please read this manual before using the device to ensure safe and proper use.
- Images may differ in appearance from the actual product. Content is subject to change without prior notice. You can access the full user manual for more information. Visit www.samsung.com to view device information, the user manual, and more.

Device layout

a	Wireless charging surface	c	Indicator light
b	Charging port		

 Wireless charging cover sold separately.

Using the wireless charger

1. Connect the travel adapter to the wireless charger. Then, place a supported mobile device in the center of the charging surface.
2. When the mobile device is fully charged, disconnect the travel adapter from the wireless charger.

 Use only Samsung-approved travel adapters (5 V/2 A).

 The travel adapter should remain close to the electric socket and easily accessible while charging.

Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

Use manufacturer-approved batteries, chargers, accessories, and supplies

Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

Do not store your device in very hot or very cold areas. It is recommended to use your device at temperatures from 5°C to 35°C

Prevent the multipurpose jack and the small end of the charger from contact with conductive materials, such as liquids, dust, metal powders, and pencil leads

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields

FCC Warning Statement

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Recycling Direct

To dispose electronics properly, follow the recycling process regulated in your area or go to Samsung

website to find the nearest recycling location:

www.samsung.com/recyclingdirect

Or call, (877) 278 – 0799.

Samsung Electronics America, Inc

85 Challenger Road,

Ridgefield Park, New Jersey, 07660

Phone: 1-800-SAMSUNG (726-7864)

BC