


2. Sample Label



3. Label Location

The label is placed inside the battery compartment

