


ANT40

9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT41


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT42


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT43


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT44


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT45


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT46


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT47


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT48


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT49


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT50


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT51


9 kHz - 150 kHz



150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT52


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT53


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT54


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT55


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT56


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT57


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3980 MHz - 26.5 GHz




ANT58


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT59


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT60

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT61


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT62


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT63


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT64


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




**BW 100MHz, Single carrier, Middle, QPSK
ANT1**


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT5


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT6


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz






ANT8


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz



150 kHz - 30 MHz



1000 MHz - 3700 MHz




Spectrum Analyzer 1
Sweep SA

KEYSTIGHT Input: RF
Coupling: AC
Ext. Gen: 14.22 dB
Freq Ref: Int (S)
PWR: Auto/None


Input 2: 50 Ω
Connectors: Off
F1: 28 dB
P1: 28 dB
P2: 28 dB
P3: 28 dB
P4: 28 dB
P5: 28 dB
P6: 28 dB
P7: 28 dB
P8: 28 dB
P9: 28 dB
P10: 28 dB
P11: 28 dB
P12: 28 dB
P13: 28 dB
P14: 28 dB
P15: 28 dB
P16: 28 dB
P17: 28 dB
P18: 28 dB
P19: 28 dB
P20: 28 dB
P21: 28 dB
P22: 28 dB
P23: 28 dB
P24: 28 dB
P25: 28 dB
P26: 28 dB
P27: 28 dB
P28: 28 dB
P29: 28 dB
P30: 28 dB
P31: 28 dB
P32: 28 dB
P33: 28 dB
P34: 28 dB
P35: 28 dB
P36: 28 dB
P37: 28 dB
P38: 28 dB
P39: 28 dB
P40: 28 dB
P41: 28 dB
P42: 28 dB
P43: 28 dB
P44: 28 dB
P45: 28 dB
P46: 28 dB
P47: 28 dB
P48: 28 dB
P49: 28 dB
P50: 28 dB
P51: 28 dB
P52: 28 dB
P53: 28 dB
P54: 28 dB
P55: 28 dB
P56: 28 dB
P57: 28 dB
P58: 28 dB
P59: 28 dB
P60: 28 dB
P61: 28 dB
P62: 28 dB
P63: 28 dB
P64: 28 dB
P65: 28 dB
P66: 28 dB
P67: 28 dB
P68: 28 dB
P69: 28 dB
P70: 28 dB
P71: 28 dB
P72: 28 dB
P73: 28 dB
P74: 28 dB
P75: 28 dB
P76: 28 dB
P77: 28 dB
P78: 28 dB
P79: 28 dB
P80: 28 dB
P81: 28 dB
P82: 28 dB
P83: 28 dB
P84: 28 dB
P85: 28 dB
P86: 28 dB
P87: 28 dB
P88: 28 dB
P89: 28 dB
P90: 28 dB
P91: 28 dB
P92: 28 dB
P93: 28 dB
P94: 28 dB
P95: 28 dB
P96: 28 dB
P97: 28 dB
P98: 28 dB
P99: 28 dB
P100: 28 dB
P101: 28 dB
P102: 28 dB
P103: 28 dB
P104: 28 dB
P105: 28 dB
P106: 28 dB
P107: 28 dB
P108: 28 dB
P109: 28 dB
P110: 28 dB
P111: 28 dB
P112: 28 dB
P113: 28 dB
P114: 28 dB
P115: 28 dB
P116: 28 dB
P117: 28 dB
P118: 28 dB
P119: 28 dB
P120: 28 dB
P121: 28 dB
P122: 28 dB
P123: 28 dB
P124: 28 dB
P125: 28 dB
P126: 28 dB
P127: 28 dB
P128: 28 dB
P129: 28 dB
P130: 28 dB
P131: 28 dB
P132: 28 dB
P133: 28 dB
P134: 28 dB
P135: 28 dB
P136: 28 dB
P137: 28 dB
P138: 28 dB
P139: 28 dB
P140: 28 dB
P141: 28 dB
P142: 28 dB
P143: 28 dB
P144: 28 dB
P145: 28 dB
P146: 28 dB
P147: 28 dB
P148: 28 dB
P149: 28 dB
P150: 28 dB
P151: 28 dB
P152: 28 dB
P153: 28 dB
P154: 28 dB
P155: 28 dB
P156: 28 dB
P157: 28 dB
P158: 28 dB
P159: 28 dB
P160: 28 dB
P161: 28 dB
P162: 28 dB
P163: 28 dB
P164: 28 dB
P165: 28 dB
P166: 28 dB
P167: 28 dB
P168: 28 dB
P169: 28 dB
P170: 28 dB
P171: 28 dB
P172: 28 dB
P173: 28 dB
P174: 28 dB
P175: 28 dB
P176: 28 dB
P177: 28 dB
P178: 28 dB
P179: 28 dB
P180: 28 dB
P181: 28 dB
P182: 28 dB
P183: 28 dB
P184: 28 dB
P185: 28 dB
P186: 28 dB
P187: 28 dB
P188: 28 dB
P189: 28 dB
P190: 28 dB
P191: 28 dB
P192: 28 dB
P193: 28 dB
P194: 28 dB
P195: 28 dB
P196: 28 dB
P197: 28 dB
P198: 28 dB
P199: 28 dB
P200: 28 dB
P201: 28 dB
P202: 28 dB
P203: 28 dB
P204: 28 dB
P205: 28 dB
P206: 28 dB
P207: 28 dB
P208: 28 dB
P209: 28 dB
P210: 28 dB
P211: 28 dB
P212: 28 dB
P213: 28 dB
P214: 28 dB
P215: 28 dB
P216: 28 dB
P217: 28 dB
P218: 28 dB
P219: 28 dB
P220: 28 dB
P221: 28 dB
P222: 28 dB
P223: 28 dB
P224: 28 dB
P225: 28 dB
P226: 28 dB
P227: 28 dB
P228: 28 dB
P229: 28 dB
P230: 28 dB
P231: 28 dB
P232: 28 dB
P233: 28 dB
P234: 28 dB
P235: 28 dB
P236: 28 dB
P237: 28 dB
P238: 28 dB
P239: 28 dB
P240: 28 dB
P241: 28 dB
P242: 28 dB
P243: 28 dB
P244: 28 dB
P245: 28 dB
P246: 28 dB
P247: 28 dB
P248: 28 dB
P249: 28 dB
P250: 28 dB
P251: 28 dB
P252: 28 dB
P253: 28 dB
P254: 28 dB
P255: 28 dB
P256: 28 dB
P257: 28 dB
P258: 28 dB
P259: 28 dB
P260: 28 dB
P261: 28 dB
P262: 28 dB
P263: 28 dB
P264: 28 dB
P265: 28 dB
P266: 28 dB
P267: 28 dB
P268: 28 dB
P269: 28 dB
P270: 28 dB
P271: 28 dB
P272: 28 dB
P273: 28 dB
P274: 28 dB
P275: 28 dB
P276: 28 dB
P277: 28 dB
P278: 28 dB
P279: 28 dB
P280: 28 dB
P281: 28 dB
P282: 28 dB
P283: 28 dB
P284: 28 dB
P285: 28 dB
P286: 28 dB
P287: 28 dB
P288: 28 dB
P289: 28 dB
P290: 28 dB
P291: 28 dB
P292: 28 dB
P293: 28 dB
P294: 28 dB
P295: 28 dB
P296: 28 dB
P297: 28 dB
P298: 28 dB
P299: 28 dB
P300: 28 dB
P301: 28 dB
P302: 28 dB
P303: 28 dB
P304: 28 dB
P305: 28 dB
P306: 28 dB
P307: 28 dB
P308: 28 dB
P309: 28 dB
P310: 28 dB
P311: 28 dB
P312: 28 dB
P313: 28 dB
P314: 28 dB
P315: 28 dB
P316: 28 dB
P317: 28 dB
P318: 28 dB
P319: 28 dB
P320: 28 dB
P321: 28 dB
P322: 28 dB
P323: 28 dB
P324: 28 dB
P325: 28 dB
P326: 28 dB
P327: 28 dB
P328: 28 dB
P329: 28 dB
P330: 28 dB
P331: 28 dB
P332: 28 dB
P333: 28 dB
P334: 28 dB
P335: 28 dB
P336: 28 dB
P337: 28 dB
P338: 28 dB
P339: 28 dB
P340: 28 dB
P341: 28 dB
P342: 28 dB
P343: 28 dB
P344: 28 dB
P345: 28 dB
P346: 28 dB
P347: 28 dB
P348: 28 dB
P349: 28 dB
P350: 28 dB
P351: 28 dB
P352: 28 dB

ANT10


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT11


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3980 MHz - 26.5 GHz

