



ANT15


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT16


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT17


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT18


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT19


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT20


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT21


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT22


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3980 MHz - 26.5 GHz




ANT23


9 kHz - 150 kHz



150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT24


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT25


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT26


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT27


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT28


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT29


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT30


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT31


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT32


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT33


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT34

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT35


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT36


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT37


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT38


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT39


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT40


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT41


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT42


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT43


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT44


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3980 MHz - 26.5 GHz




ANT45


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3980 MHz - 26.5 GHz

