



ANT5


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT6


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT7


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT8


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT9


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT10


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT11


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT12


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT13


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT14


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT15


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT17


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT18


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT19


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT20


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT21


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz








3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz




150 kHz - 30 MHz




ANT23


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT24


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT25


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT26


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT27


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz




ANT28


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz



ANT29


9 kHz - 150 kHz



150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT30


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT31


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz




3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




150 kHz - 30 MHz



1000 MHz - 3700 MHz




4000 MHz - 26.5 GHz




ANT33


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT34


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT35


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT36


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT37


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT38


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz

