



ANT9


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT10


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT11


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT12


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT13


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT14


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT15


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT16

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT17


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT18


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT19


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT20


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT21


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT22


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT23

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT24


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT25


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT26


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT27


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT28


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT29


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT30


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT31


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT32


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT33


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT34


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT35


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT36


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT37


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT38


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT39


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT40


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT41


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3980 MHz - 26.5 GHz




ANT42


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3980 MHz - 26.5 GHz

