



ANT19


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT20


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT21

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT22


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT23


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz




3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




150 kHz - 30 MHz



1000 MHz - 3700 MHz




4000 MHz - 26.5 GHz




ANT25


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT27


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz




3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz






ANT29


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT30


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT31


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT32


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT33


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT34


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT35


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT36


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT37


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT38


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT39


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT40


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT41


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT42


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT43


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT44


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT45


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT46


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT47


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT48


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT49


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT50


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT51


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT52


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz

