



ANT41


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT42


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT43


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT44


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT45


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT46


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT47


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT48


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT49


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT50


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT51


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT52


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT53


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT54


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT55


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT56


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT57


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT58


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT59


9 kHz - 150 kHz



150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT60


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT61


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT62


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT63


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT64


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3700 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




**BW 100MHz + BW 100MHz, Multi carrier(Non-contiguous), Bottom+Top, QPSK
ANT1**

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz




3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz




150 kHz - 30 MHz



1000 MHz - 3690 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz




ANT4


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT5


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz




ANT6

9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 3690 MHz




3690 MHz - 3699 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT7


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3981 MHz - 4000 MHz




4000 MHz - 26.5 GHz



ANT8


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz




3690 MHz - 3699 MHz



3981 MHz - 4000 MHz



4000 MHz - 26.5 GHz




ANT9


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 3690 MHz



3690 MHz - 3699 MHz



3981 MHz - 4000 MHz

