



ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75GHz




12.75GHz - 26.5GHz




**Band 25, BW 10MHz, Single carrier, Bottom, 64QAM
ANT0**


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75GHz




12.75GHz - 26.5GHz




ANT1


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75GHz




12.75GHz - 26.5GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75GHz




12.75GHz - 26.5GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75GHz




12.75GHz - 26.5GHz




**Band 25, BW 10MHz, Single carrier, Middle, QPSK
ANT0**


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT1


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




**Band 25, BW 10MHz, Single carrier, Middle, 64QAM
ANT0**


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT1


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz



1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




**Band 25, BW 10MHz, Single carrier, Top, QPSK
ANT0**


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT1


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




**Band 25, BW 10MHz, Single carrier, Top, 64QAM
ANT0**


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT1


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz



1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz



12.75 GHz - 26.5 GHz




ANT2


9 kHz - 150 kHz




150 kHz - 30 MHz




30 MHz - 1000 MHz




1000 MHz - 1919 MHz



1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz




12.75 GHz - 26.5 GHz




ANT3


9 kHz - 150 kHz




150 kHz - 30 MHz



30 MHz - 1000 MHz




1000 MHz - 1919 MHz




1919 MHz - 1929 MHz



1996 MHz - 2001 MHz



2001 MHz - 12.75 GHz



12.75 GHz - 26.5 GHz

