

External photos of EUT


Front view of EUT



Rear view of EUT





Top view of EUT



Bottom view of EUT



Side view of EUT



External view of client device with receiver (SM-N910V)



Client device is placed directly in contact with the transmitter

