



Attachment 8.



- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information




★ Distance between Main antenna and edge





SAR Test Setup Photographs

■ Test Setup Photo(Left All)




■ Test Setup Photo(Left Touch/Tilt)



■ **Test Setup Photo (Right All)**



■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**




■ **Setup Photo (Rear)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 11 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 7 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 10 mm from the EUT]

■ Test Setup Photo (Right)



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Right)



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Top)




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 12 mm from the EUT]