


Attachment 8.

- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information



SAR Test Setup Photographs



■ **Test Setup Photo(Head All)**



■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**



■ Test Setup Photo (Rear)




[Distance of 0 mm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 10 mm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 15 mm from the EUT]

■ Test Setup Photo (Left)



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Left)



[Distance of 10 mm from the EUT]

■ Test Setup Photo (Right)



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 10 mm from the EUT]