



Antenna and Device Information

* Distance between BT/WLAN antenna and Main antenna




* Diagonal dimension of LCD and device




SAR Test Setup Photographs

■ Test Setup Photo (Left All)



■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)



■ Test Setup Photo (Right Touch/Tilt)



■ Test Setup Photo (Body All)



■ Test Setup Photo (Rear)



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Right)



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 1.5 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.5 cm** from the EUT]