





Antenna and Device Information



* Distance between BT/WLAN antenna and edge



* Diagonal dimension of device and display




SAR Test Setup Photographs

■ Test Setup Photo (Left All)



■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)




■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 1.5 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of **1.0 cm** from the EUT]

■ Test Setup Photo (Left)



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]