


Attachment 8.


- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information


* Placement of each antenna




* Distance between Main antenna and edge



* Distance between BT/WLAN antenna and edge



* Diagonal dimension of display and device



SAR Test Setup Photographs

■ Test Setup Photo(Left All)



■ Test Setup Photo(Left Touch/Tilt)



■ **Test Setup Photo (Right All)**




■ **Test Setup Photo (Right Touch/Tilt)**



■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Top)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Bottom)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 1.5 cm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 1.5 cm from the EUT]