



Antenna and Device Information



* Distance between BT/WLAN antenna and Main antenna



* Distance between Main antenna and edge



Distance between Bluetooth antenna and edge



SAR Test Setup Photographs


■ Test Setup Photo (Left All)



■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)




■ Test Setup Photo (Right Touch/Tilt)



■ Test Setup Photo (Body All)




■ **Test Setup Photo (Rear)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 1.5 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Spacer) 10 mm



■ Test Setup Photo(Spacer) 15 mm

