




Antenna and Device Information




* Distance between BT/WLAN antenna and Main antenna



* Distance between Main antenna and edge




* Outside Size





SAR Test Setup Photographs

■ Test Setup Photo (Left All)




■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)



■ Test Setup Photo (Right Touch/Tilt)



■ Test Setup Photo (Body All)




■ Test Setup Photo (Rear)




[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 1.5 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.0 cm** from the EUT]

■ Test Setup Photo (Left)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Right)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Top)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Bottom)



[Distance of 1.0 cm from the EUT]