





Antenna and Device Information





* Diagonal dimension of Display and Device



SAR Test Setup Photographs

■ **Test Setup Photo (Left All)**




■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)




■ **Test Setup Photo (Right Touch/Tilt)**



■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 1.5 cm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]

■ **Extremity SAR Test Setup Rear (0mm)**



[Distance of 0 cm from the EUT]

■ **Extremity SAR Test Setup Front (0mm)**



[Distance of 0 cm from the EUT]

■ **Extremity SAR Test Setup Left side (0mm)**



[Distance of 0 cm from the EUT]

■ **Extremity SAR Test Setup Right side (0mm)**



[Distance of 0 cm from the EUT]

■ **Extremity SAR Test Setup Top (0mm)**



[Distance of 0 cm from the EUT]