




Attachment 8.

- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS


DUT Antenna Information



* Distance between Main antenna and edge



* Distance between BT/WLAN antenna and edge




SAR Test Setup Photographs

■ Test Setup Photo(Left All)





■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)




■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**




■ Test Setup Photo (Rear)




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 10 mm from the EUT]

■ Test Setup Photo (Right)




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 10 mm from the EUT]