


SAMSUNG

**M O B I L E
D E V I C E**



**Health & Safety and
Warranty Guide**

**Please read this manual
before operating your
device and keep it
for future reference.**





Warning! This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, please call 1-800-SAMSUNG (726-7864).



Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property





R732_EN_HS_PS_090215_R2









of Samsung or its respective suppliers relating to the SAMSUNG mobile device, including but not limited to, accessories, parts, or software relating thereto (the "mobile device"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may







not infringe or otherwise
violate the rights secured by
the Intellectual Property.
Moreover, you agree that you
will not (and will not attempt to)
modify, prepare derivative
works of, reverse engineer,
decompile, disassemble, or
otherwise attempt to create
source code from the software.
No title to or ownership in the
Intellectual Property is
transferred to you. All
applicable rights of the
Intellectual Property shall
remain with SAMSUNG and its
suppliers.





Open Source Software

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:
<http://opensource.samsung.com>.





**Disclaimer of
Warranties;
Exclusion of
Liability**

EXCEPT AS SET FORTH IN THE
EXPRESS WARRANTY
CONTAINED ON THE
WARRANTY PAGE ENCLOSED
WITH THE PRODUCT, THE
PURCHASER TAKES THE
PRODUCT "AS IS", AND
SAMSUNG MAKES NO
EXPRESS OR IMPLIED
WARRANTY OF ANY KIND
WHATSOEVER WITH RESPECT
TO THE PRODUCT, INCLUDING







BUT NOT LIMITED TO THE
MERCHANTABILITY OF THE
PRODUCT OR ITS FITNESS FOR
ANY PARTICULAR PURPOSE OR
USE; THE DESIGN, CONDITION
OR QUALITY OF THE PRODUCT;
THE PERFORMANCE OF THE
PRODUCT; THE WORKMANSHIP
OF THE PRODUCT OR THE
COMPONENTS CONTAINED
THEREIN; OR COMPLIANCE OF
THE PRODUCT WITH THE
REQUIREMENTS OF ANY LAW,
RULE, SPECIFICATION OR
CONTRACT PERTAINING
THERETO. NOTHING
CONTAINED IN THE
INSTRUCTION MANUAL SHALL







BE CONSTRUED TO CREATE AN
EXPRESS OR IMPLIED
WARRANTY OF ANY KIND
WHATSOEVER WITH RESPECT
TO THE PRODUCT. IN
ADDITION, SAMSUNG SHALL
NOT BE LIABLE FOR ANY
DAMAGES OF ANY KIND
RESULTING FROM THE
PURCHASE OR USE OF THE
PRODUCT OR ARISING FROM
THE BREACH OF THE EXPRESS
WARRANTY, INCLUDING
INCIDENTAL, SPECIAL OR
CONSEQUENTIAL DAMAGES,
OR LOSS OF ANTICIPATED
PROFITS OR BENEFITS.







Modification of Software

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.



USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.



**Samsung
Electronics
America (SEA), Inc**

Address:
85 Challenger Road
Ridgefield Park,
New Jersey 07660

Phone:
1-800-SAMSUNG (726-7864)

Internet Address:
www.samsung.com



©2015 Samsung Electronics
America, Inc. Samsung is a
registered trademark of
Samsung Electronics Co., Ltd.

Do you have questions about
your Samsung Mobile Device?
For 24 hour information and
assistance, we offer a new
FAQ/ARS System (Automated
Response System) at:
www.samsung.com/us/support









Table of Contents

Section 1:

Health and Safety 4

Maintaining Water and Dust Resistance	8
FCC Part 15 Information to User	11
Samsung Mobile Products and Recycling	15
Smart Practices While Driving	20
Battery Use and Safety . .	26
UL Certified Travel Charger	35
Display / Touch-Screen .	38



GPS	40
Care and Maintenance ..	42
Responsible Listening ..	50
Operating Environment ..	61
Restricting Children's Access to Your Mobile Device	71
FCC Notice and Cautions	72
Other Important Safety Information	74
Section 2:	
Warranty Information ..	81
Standard Limited Warranty	82
End User License Agreement for Software (EULA) ...	108





Section 1: Health and Safety

This section outlines the safety precautions associated with using your device. The terms "device" or "mobile device" are used in this section to refer to your Gear. **Read this information before using your mobile device.**





Note: Use manufacturer-approved batteries, chargers, accessories, and supplies.







Caution! If you feel discomfort while using the device, stop using it and remove it from your wrist. If your device becomes hot to the touch, please remove it until it cools.





Note: Water-resistant and dustproof based on IP68 rating, which tests submersion up to 1.5 meters for up to 30 minutes.







Note: When the Gear is synced with a compatible S Health app, you can use additional features. These additional features include checking your exercise records, and more. The accuracy of the heart rate sensor may be diminished depending on skin condition, or measurement conditions and surroundings. Take heart rate measurements when you are seated and relaxed.





Caution! This device, S Health,
and related software is
not intended for use in
the diagnosis of
disease or other
conditions, or in the
cure, mitigation,
treatment or prevention
of disease.



Note: Do not look directly at the
heart rate sensor's lights.
Doing so may impair your
vision.







Maintaining Water and Dust Resistance

This device is rated IP68 using
the Ingress Protection rating
system.

Your device has been tested in
a controlled environment and
shown to be water and dust
resistant in certain
circumstances (meets
requirements of classification
IP68 as described by the
international standard IEC
60529 - Degrees of Protection
provided by Enclosures [IP
Code]; test conditions:

Health and Safety 8









15-35°C, 86-106 kPa, 1.5 meter, for 30 minutes). Despite this classification, your device is not impervious to water damage in any situation. It is important that all compartments are closed tightly.



Follow these tips carefully to prevent damage to the device.

- Whenever your device gets wet, dry it thoroughly with a clean, soft cloth.





- Do not expose the device to salt water or ionized water, or to water over 1.5 meter deep for more than 30 minutes. If your device is exposed to fresh water, dry it thoroughly with a clean, soft cloth. If the device is exposed to any liquid other than fresh water, rinse the device with fresh water immediately and dry it thoroughly with a clean, soft cloth. Failure to rinse the device in fresh water and dry it as instructed may cause the device to suffer from operability or cosmetic issues.



- Do not expose the device to water at high pressure, such as ocean waves or a waterfall.
- If the device is dropped or receives an impact, the water and dust resistant features of the device may be damaged.
- The touchscreen and other features may not work properly if the device is used in water or in other liquids.

FCC Part 15 Information to User



Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications



not expressly approved by
Samsung could void your
authority to operate the device.

This device complies with part
15 of the FCC Rules. Operation
is subject to the following two
conditions: (1) This device may
not cause harmful interference,
and (2) this device must accept
any interference received,
including interference that may
cause undesired operation.



Note: This equipment has been
tested and found to comply
with the limits for a Class B
digital device, pursuant to part
15 of the FCC Rules. These





limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.





However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the





equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Samsung Mobile Products and Recycling

Samsung cares for the environment and encourages its customers to recycle Samsung mobile devices and genuine Samsung accessories.

Proper disposal of your mobile device and its battery is not only important for safety, it benefits the environment.

Batteries must be recycled or disposed of properly.

Note: Dispose of unwanted electronics through an approved recycler.

We've made it easy for you to recycle your old Samsung mobile device by working with respected take-back companies in every state in the country.

Note: Most carriers will provide a take-back option for products to be properly disposed when purchasing new products.

For battery recycling,
go to call2recycle.org
or call **1-800-822-8837**.



Drop It Off

You can drop off your
Samsung-branded mobile
device and batteries for
recycling at one of our
numerous Samsung
Recycling Direct (SM)
locations.

Note: Samsung-branded
devices and batteries will
be accepted at these
locations for no fee.

To find the nearest recycling location, go to any of the following:

- www.samsung.com/recyclingdirect or call 1-877-278-0799.
- PLUG-IN to eCYCLING with EPA: www.call2recycle.org/

Mail It In

The Samsung Mobile Take-Back Program will provide Samsung customers with a free recycling mailing label.

For more information, go to: <https://pages.samsung.com/>

Health and Safety 18

[recycling/index.jsp](#) and follow
the on-screen instructions
or call 1-800-822-8837.

**Follow local regulations
regarding disposal of mobile
devices and batteries**

Dispose of your mobile device
and batteries in accordance
with local regulations. In some
areas, the disposal of these
items in household or business
trash may be prohibited. Help
us protect the environment -
recycle!

Warning! Never dispose of batteries in a fire because they may explode.

Smart Practices While Driving

On the Road - Off the Device



The primary responsibility of every driver is the safe operation of his or her vehicle. Responsible drivers understand that no secondary task should be performed while driving whether it be eating, drinking, talking to passengers, or using

a mobile device - unless the driver has assessed the driving conditions and is confident that the secondary task will not interfere with their primary responsibility. **Do not engage in any activity while driving a moving vehicle which may cause you to take your eyes off the road or become so absorbed in the activity that your ability to concentrate on the act of driving becomes impaired.** Samsung is committed to promoting responsible driving and giving drivers the tools they need to understand and address distractions.



Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. For example, only hands-free use may be permitted in certain areas.



Before using your device to chat with friends, consider your circumstances. Let the chat wait when driving conditions require. Remember, driving comes first, nothing else!





If you consider a chat
necessary and appropriate,
follow these tips:

- Use a hands-free device;
- Secure your mobile device
within easy reach;
- Chat when you are not moving;
- Plan chats when your car will be
stationary;
- Do not engage in stressful or
emotional conversations;
- Let the person with whom you
are speaking know that you are
driving and will suspend the
chat if necessary;







- Do not take notes or look up information while driving;

Notice regarding legal restrictions on mounting this device in an automobile:

Laws in some states may prohibit mounting this device on or near the windshield of an automobile. In other states, the law may permit mounting this device only in specific locations in the automobile. Be sure to consult the state and local laws or ordinances where you drive before mounting this device in an automobile. Failure to



comply with these restrictions could result in fines, penalties, or other damages.

Never mount this device in a manner that will obstruct the driver's clear view of the street and traffic.

Never use wireless data services such as Web browsing or e-mail while operating a vehicle.

Never watch videos, such as a movie or clip, or play video games while operating a vehicle.

For more information, go to www.ctia.org.

Battery Use and Safety

The battery in your device is not intended to be replaced by the consumer. If you believe the battery is damaged or

needs to be replaced, take the device to a service center for inspection and replacement.

- **Do not let the device or battery come in contact with liquids.** Liquids can get into the device's circuits, leading to corrosion. Even when the device appears to be dry and appears to operate normally, the circuitry could slowly corrode and pose a safety hazard. If the device and/or battery get wet, have them checked by your service provider or contact Samsung, even if they appear to be





working properly.

- **Do not place your battery in or near a heat source.** Excessive heating can damage the device or the battery and could cause the device or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron, or radiator. Avoid leaving your device in your car in high temperatures.



• **Caution: Some applications or prolonged usage may increase device temperature.**

Prolonged skin contact with a device that is hot to the touch may produce skin discomfort or redness, or low-temperature burns. If the device feels hot to the touch, discontinue use and close all applications or turn off the device until it cools. Always ensure that the device has adequate ventilation and air flow. Covering the device with



bedding, your body, thick clothing or any other materials that significantly affect air flow may affect the performance of the device and poses a possible risk of fire or explosion, which could lead to serious bodily injuries or damage to property.

- **Do not dispose of the device or the battery in a fire.** The device or the battery may explode when overheated.

- **Avoid dropping the device.**

Dropping the device, especially on a hard surface, can potentially cause damage to the device. If you suspect damage to the device or battery, take it to a service center for inspection.

- **Never use any charger or battery that is damaged in any way.**



Important! Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers which are specifically designed for your device.

WARNING!
Use of a non-Samsung-approved battery or charger may present a risk of fire, explosion, leakage, or other hazard. Samsung's warranty





does not cover damage to the device caused by non-Samsung-approved batteries and/or chargers.

- **Do not use incompatible batteries and chargers.** Some websites and second-hand dealers not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers.





Consumers should purchase manufacturer or carrier-recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.



- Misuse or use of incompatible batteries and charging devices could result in damage to the equipment and a possible risk of fire, explosion, or leakage, leading to serious injuries, damages to your device, or other serious hazard.

UL Certified Travel Charger

The Travel Charger for this mobile device has met applicable UL safety

requirements. Please adhere to
the following safety
instructions per UL guidelines:

**FAILURE TO FOLLOW THE
INSTRUCTIONS OUTLINED
MAY LEAD TO SERIOUS
PERSONAL INJURY AND
POSSIBLE PROPERTY
DAMAGE.**


**IMPORTANT SAFETY
INSTRUCTIONS - SAVE
THESE INSTRUCTIONS.**

**DANGER - TO
REDUCE THE RISK
OF FIRE OR
ELECTRIC SHOCK,**

Health and Safety 36

**CAREFULLY FOLLOW
THESE
INSTRUCTIONS.**

FOR CONNECTION
TO A SUPPLY NOT
IN NORTH
AMERICA, USE AN
ATTACHMENT PLUG
ADAPTOR OF THE
PROPER
CONFIGURATION
FOR THE POWER
OUTLET.
THIS POWER UNIT
IS INTENDED TO BE
CORRECTLY
ORIENTED IN A
VERTICAL OR



HORIZONTAL OR
FLOOR MOUNT
POSITION.

Display / Touch-Screen

Please note the following
information when using your
mobile device:

WARNING REGARDING DISPLAY



The display on your
mobile device is made of
glass or acrylic and could
break if your mobile
device is dropped or if it



receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.



**WARRANTY DISCLAIMER:
PROPER USE OF A
TOUCH-SCREEN MOBILE
DEVICE**

If your mobile device has a touch-screen display, please note that a touch-screen responds best to a light touch from the pad of your finger or a non-metallic stylus.





Using excessive force or a metallic object when pressing on the touch-screen may damage the tempered glass surface and void the warranty. For more information, please refer to the “Standard Limited Warranty”.



GPS

The device does not use a Global Positioning System (GPS) signal for location-based applications. However, your paired device may do so.







Please consult the Health and Safety and Warranty Guide for your paired device for more information.

Navigation

Maps, directions, and other navigation-data, including data relating to your current location, may contain inaccurate or incomplete data, and circumstances can and do change over time. In some areas, complete information may not be available.

Therefore, you should always visually confirm that the navigational instructions are consistent with what you see







before following them. All users should pay attention to road conditions, closures, traffic, and all other factors that may impact safe driving or walking. Always obey posted road signs.

Care and Maintenance

Your mobile device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years:



**Keep your Samsung Mobile
Device away from:**

**Deliberate exposure to
liquids of any kind**



Please refer to instructions
for adhering to IP68
certification parameters
and make sure that liquid
exposure of the device
does not exceed these
limitations. Precipitation,
humidity, and liquids
contain minerals that will
corrode electronic circuits.

If the mobile device does
get wet, do not accelerate
drying with the use of an

oven, microwave, or dryer, because this may damage the mobile device and could cause a fire or explosion. Do not use the mobile device in very wet conditions. Doing so may cause an electric shock to you or damage to the mobile device. Do not expose the straps to very wet conditions. Wet straps can cause skin irritations. Dry the straps first. If you experience skin irritation when wearing the device, stop wearing the device and consult a physician.



Note: Do not use your device
outdoor during a
thunderstorm.



Extreme heat or cold

Avoid temperatures below
0°C / 32°F or above 45°C /
113°F. C. Using or storing
the device outside of the
recommended temperature
ranges may damage the
device or reduce the
battery's lifespan.

Microwaves

Do not try to dry your
mobile device in a







microwave oven. Doing so
may cause a fire or
explosion.

Dust and dirt

Do not expose your mobile
device to dust, dirt, or sand.

Cleaning solutions

Do not use harsh
chemicals, cleaning
solvents, or strong
detergents to clean the
mobile device. Wipe it with
a soft cloth slightly
dampened in a mild
soap-and-water solution. If
the mobile device has a
retractable camera lens, do







not use soap and water to clean the lens. Use a blower or brush or lens cleaning paper dampened in a lens cleaning solution.

Shock or vibration

Do not drop, knock, or shake the mobile device. Rough handling can break internal circuit boards.

Paint

Do not paint the mobile device. Paint can clog the device's moving parts or ventilation openings and prevent proper operation.



Strap

Ensure that the strap is kept clean.



Bluetooth

Do not touch the Bluetooth antenna of a connected mobile device.

- Samsung is not responsible for the loss, interception, or misuse of data sent or received via the Bluetooth feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured.



- Some devices, especially those that are not tested or approved by the Bluetooth SIG, may not be compatible with your device.





Important! Do not allow the touch screen to come into contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.





Caution! To avoid damaging the touch screen, do not tap it with anything sharp or apply excessive pressure to it with your fingertips.



Responsible Listening

Caution! Avoid potential hearing loss.





Damage to hearing occurs when a person is exposed to loud sounds over time. The risk





of hearing loss increases as sound is played louder and for longer durations.

Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss. Some scientific research suggests that using portable audio devices, such as portable music players and cell phones, at high volume settings for long durations may lead to permanent noise-induced hearing loss. This includes the use of headphones (including







headsets, earbuds, and Bluetooth® or other wireless devices).

Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound, and distorted hearing. Individual susceptibility to noise-induced hearing loss and potential hearing problem varies.

Additionally, the amount of sound produced by a portable audio device varies depending on the nature of the sound, the device settings, and the headphones that are used. As a







result, there is no single volume setting that is appropriate for everyone or for every combination of sound, settings, and equipment.



You should follow some common sense recommendations when using any portable audio device:

- Always turn the volume down before plugging the earphones into an audio source.
- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.







- Be aware that you can adapt to higher volume settings over time, not realizing that the higher volume may be harmful to your hearing.
- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.







- Do not turn the volume up to block out noisy surroundings. If you choose to listen to your portable device in a noisy environment, use noise-cancelling headphones to block out background environmental noise. By blocking background environment noise, noise cancelling headphones should allow you to hear the music at lower volumes than when using earbuds.







- Limit the amount of time you listen. As the volume increases, less time is required before you hearing could be affected.
- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss. Temporary hearing loss might cause unsafe volumes to sound normal.





- Do not listen at any volume that causes you discomfort. If you experience ringing in your ears, hear muffled speech, or experience any temporary hearing difficulty after listening to your portable audio device, discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:





R732_book Page 58 Wednesday, September 15, 2010 5:40 PM



American Academy of Audiology

11480 Commerce Park Drive,
Suite 220



Reston, VA 20190

Voice: (800) 222-2336 or
703-790-8466

Email: infoaud@audiology.org

Internet:

[www.audiology.org/Pages/
default.aspx](http://www.audiology.org/Pages/default.aspx)



Health and Safety 58







**National Institute on Deafness
and Other Communication
Disorders**

National Institutes of Health
31 Center Drive, MSC 2320
Bethesda, MD 20892-2320

Email:
nidcdinfo@nidcd.nih.gov

Internet:
www.nidcd.nih.gov/



**National Institute for
Occupational Safety and Health
(NIOSH)**

395 E Street, S.W., Suite 9200
Patriots Plaza Building
Washington, DC 20201
1-800-CDC-INFO
(1-800-232-4636)
Outside the U.S. 513-533-8328
TTY: (888) 232-6348

Email: cdcinfo@cdc.gov

Internet:

[www.cdc.gov/niosh/topics/noise/
default.html](http://www.cdc.gov/niosh/topics/noise/default.html)



Operating Environment

Remember to follow any special regulations in force in any area, and always switch your mobile device off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the mobile device or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.



Using Your Mobile Device Near Other Electronic Devices

Most modern electronic equipment is shielded from Radio Frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless mobile device. Consult the manufacturer to discuss alternatives.





Implantable Medical Devices

A minimum separation of six (6) inches should be maintained between a handheld wireless mobile device and an implantable medical device, such as a pacemaker or implantable cardioverter defibrillator, to avoid potential interference with the device.

Persons who have such devices:



- Should ALWAYS keep the mobile device more than six (6) inches from their implantable medical device when the mobile device is turned ON;
- Should not carry the mobile device in a breast pocket;
- Should use the ear opposite the implantable medical device to minimize the potential for interference;
- Should turn the mobile device OFF immediately if there is any reason to suspect that interference is taking place;



- Should read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless mobile device with an implantable medical device, consult your health care provider.



For more information see:
www.fcc.gov/oet/rfsafety/rf-fags.html#.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to



determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your mobile device off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.



Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the



manufacturer or its representative regarding your vehicle before using your mobile device in a motor vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch your mobile device off in any facility where posted notices require you to do so.

Potentially Explosive Environments

Switch your mobile device off when in any area with a potentially explosive

atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised to switch the mobile device off while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly



marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58).



For a copy of this standard,
contact the National Fire
Protection Association.

When your Device is Wet

Do not turn on your device if it
is wet. If your device is already
on, turn it off and remove the
battery immediately (if the
device will not turn off or you
cannot remove the battery,
leave it as-is). Then, dry the
device with a towel and take it
to a service center.



Restricting Children's Access to Your Mobile Device

Your mobile device is not a toy.
Do not allow children to play
with it because they could hurt
themselves and others,
damage the mobile device, or
make calls that increase your
mobile device bill.

Keep the mobile device and all
its parts and accessories out of
the reach of small children.

FCC Notice and Cautions

FCC Notice



The mobile device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the mobile device if such interference cannot be eliminated.

Cautions

Any changes or modifications to your mobile device not expressly approved by Samsung could void your warranty for this equipment



and void your authority to
operate this equipment. Only
use approved batteries,
antennas, and chargers.




The use of any unauthorized
accessories may be dangerous
and void the mobile device
warranty if said accessories
cause damage or a defect to
the mobile device. Although
your mobile device is quite
sturdy, it is a complex piece of
equipment and can be broken.
Avoid dropping, hitting,
bending, or sitting on it.



Other Important Safety Information



- Only qualified personnel should service the mobile device. Faulty service may be dangerous and may invalidate any warranty applicable to the device.
- Ensure that any mobile devices or related equipment used in your vehicle are securely mounted.
- Check regularly that all wireless mobile device equipment in your vehicle is mounted and operating properly.



- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the mobile device, its parts, or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including installed or portable wireless equipment near or in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.





- Switch your mobile device off before boarding an aircraft. The use of wireless mobile devices in aircraft may be illegal and may be dangerous to the aircraft's operation. Check with appropriate authorities before using any function of a mobile device while on an aircraft.
- Failure to observe these instructions may lead to the suspension or denial of network services to the offender, or legal action, or both.









- While using your device, leave some lights on in the room and do not hold the screen too close to your eyes.
- Seizures or blackouts can occur when you are exposed to flashing lights while watching videos or playing games for extended periods. If you feel any discomfort, stop using the device immediately.







- Reduce risk of repetitive motion injuries. When you repetitively perform actions, such as pressing keys, drawing characters on a touch screen with your fingers, or playing games, you may experience occasional discomfort in your hands, neck, shoulders, or other parts of your body. When using





your device for extended periods, hold the device with a relaxed grip, press the keys lightly, and take frequent breaks. If you continue to have discomfort during or after such use, stop use and see a physician.

- If your device has a camera flash or light, do not use the flash or light close to the eyes of people or pets. [010115]



Section 2: Warranty Information

SAMSUNG ELECTRONICS
AMERICA, INC. ("SAMSUNG")
warrants that SAMSUNG's
devices and accessories
("Products") are free from
defects in material and
workmanship under normal
use and service.

Samsung Electronics America,
Inc.
85 Challenger Road



Ridgefield Park, New Jersey
07660
Phone: 1-800-SAMSUNG
(726-7864)



Standard Limited Warranty

What is covered and for how long?

The warranty period
commences upon the date of
purchase by the first consumer
purchaser and continuing for
the following specified period
of time after that date:

Device	1 Year
--------	--------

Warranty Information	82
----------------------	----







Battery(ies)* 1 Year
Other Accessories* 1 Year

*If applicable.

What is not covered?



This Limited Warranty is
conditioned upon proper use of
the Product.

This Limited Warranty does not
cover: (a) defects or damage
resulting from accident,
misuse, abnormal use,
abnormal conditions, improper
storage, exposure to liquid,
moisture, dampness, sand or
dirt, neglect, or unusual
physical, electrical or





electromechanical stress;
(b) scratches, dents and cosmetic damage, unless caused by SAMSUNG;
(c) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen;
(d) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible;
(e) ordinary wear and tear;
(f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or



ancillary/peripheral equipment not furnished or approved by SAMSUNG; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG, including but not limited to installation of unauthorized software and unauthorized root access, both of which shall void this limited warranty; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning,

earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source;
(i) defects or damage resulting from cellular signal reception or transmission, or viruses or other software problems introduced into the Product; or
(j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has

been charged by a battery charger not specified or approved by SAMSUNG for charging the battery; (ii) any of the seals on the battery are broken or show evidence of tampering; or (iii) the battery has been used in equipment other than the SAMSUNG device for which it is specified.

What are SAMSUNG's obligations?

During the applicable warranty period, provided the Product is returned in accordance with the terms of this Limited Warranty, SAMSUNG will repair

or replace the Product, at SAMSUNG's sole option, without charge. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product, or may replace the Product with a rebuilt, reconditioned or new Product. Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/ replaced Products will be warranted for a period equal to the remainder of the original Limited Warranty on the

Warranty Information 88



original Product or for ninety (90) days, whichever is longer. All replaced Products, parts, components, boards and equipment shall become the property of SAMSUNG. Except to any extent expressly allowed by applicable law, transfer or assignment of this Limited Warranty is prohibited.

What must you do to obtain warranty service?

To obtain service under this Limited Warranty, you must return the Product to an authorized phone service facility in an adequate



container for shipping,
accompanied by the sales
receipt or comparable proof of
sale showing the original date
of purchase by the first
consumer purchaser, the serial
number of the Product and the
seller's name and address.



To obtain assistance on where
to deliver the Product, please
call SAMSUNG Customer Care
at 1-800-SAMSUNG
(726-7864). If SAMSUNG
determines that any Product is
not covered by this Limited
Warranty, you must pay all



parts, shipping, and labor charges for the repair or return of such Product.

You should keep a separate backup copy of any contents of the Product before delivering the Product to SAMSUNG for warranty service, as some or all of the contents may be deleted or reformatted during the course of warranty service.

What are the limits on SAMSUNG's liability?

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF SAMSUNG'S



RESPONSIBILITIES, AND THE
EXCLUSIVE REMEDY
REGARDING THE PRODUCTS.
ALL IMPLIED WARRANTIES,
INCLUDING WITHOUT
LIMITATION, IMPLIED
WARRANTIES OF
MERCHANTABILITY AND
FITNESS FOR A PARTICULAR
PURPOSE, ARE LIMITED TO
THE DURATION OF THIS
LIMITED WARRANTY. IN NO
EVENT SHALL SAMSUNG BE
LIABLE FOR DAMAGES IN
EXCESS OF THE PURCHASE
PRICE OF THE PRODUCT OR
FOR, WITHOUT LIMITATION,
COMMERCIAL LOSS OF ANY



Warranty Information 92



SORT; LOSS OF USE, TIME,
DATA, REPUTATION,
OPPORTUNITY, GOODWILL,
PROFITS OR SAVINGS;
INCONVENIENCE; INCIDENTAL,
SPECIAL, CONSEQUENTIAL OR
PUNITIVE DAMAGES; OR
DAMAGES ARISING FROM THE
USE OR INABILITY TO USE THE
PRODUCT. SOME STATES AND
JURISDICTIONS DO NOT
ALLOW LIMITATIONS ON HOW
LONG AN IMPLIED WARRANTY
LASTS, OR THE DISCLAIMER
OR LIMITATION OF INCIDENTAL
OR CONSEQUENTIAL
DAMAGES, SO THE ABOVE



LIMITATIONS AND
DISCLAIMERS MAY NOT APPLY
TO YOU.



SAMSUNG MAKES NO
WARRANTIES OR
REPRESENTATIONS, EXPRESS
OR IMPLIED, STATUTORY OR
OTHERWISE, AS TO THE
QUALITY, CAPABILITIES,
OPERATIONS, PERFORMANCE
OR SUITABILITY OF ANY
THIRD-PARTY SOFTWARE OR
EQUIPMENT USED IN
CONJUNCTION WITH THE
PRODUCT, OR THE ABILITY TO
INTEGRATE ANY SUCH
SOFTWARE OR EQUIPMENT
WITH THE PRODUCT, WHETHER





Warranty Information 94







SUCH THIRD-PARTY
SOFTWARE OR EQUIPMENT IS
INCLUDED WITH THE PRODUCT
DISTRIBUTED BY SAMSUNG OR
OTHERWISE. RESPONSIBILITY
FOR THE QUALITY,
CAPABILITIES, OPERATIONS,
PERFORMANCE AND
SUITABILITY OF ANY SUCH
THIRD-PARTY SOFTWARE OR
EQUIPMENT RESTS SOLELY
WITH THE USER AND THE
DIRECT VENDOR, OWNER OR
SUPPLIER OF SUCH
THIRD-PARTY SOFTWARE OR
EQUIPMENT.





Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Products. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of SAMSUNG regarding the Products or this Limited Warranty.







This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from state to state.



What is the procedure for resolving disputes?

ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCTS SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY.





Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's Product or claim, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to



consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty.

For any arbitration in which your total damage claims, exclusive of attorney fees and

expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant SAMSUNG its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and SAMSUNG shall

pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction.

This arbitration provision also applies to claims against SAMSUNG's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

You may opt out of this dispute resolution procedure by providing notice to SAMSUNG no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product. To opt out, you must send notice by e-mail to optout@sea.samsung.com, with the subject line: "Arbitration Opt Out." You must include in the opt

Warranty Information 102

out e-mail (a) your name and address; (b) the date on which the Product was purchased; (c) the Product model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the Product box; (ii) on the Product information screen, which can be found under “Settings;” (iii) on a label on the back of the Product beneath the battery, if the battery is removable; and (iv) on the outside of the Product if the battery is not removable). Alternatively, you

may opt out by calling
1-800-SAMSUNG (726-7864) no
later than 30 calendar days from
the date of the first consumer
purchaser's purchase of the
Product and providing the same
information. These are the only
two forms of notice that will be
effective to opt out of this
dispute resolution procedure.
Opting out of this dispute
resolution procedure will not
affect the coverage of the
Limited Warranty in any way,
and you will continue to enjoy
the benefits of the Limited
Warranty.

Severability

If any portion of this Limited Warranty is held to be illegal or unenforceable, such partial illegality or unenforceability shall not affect the enforceability of the remainder of the Limited Warranty.



Precautions for Transfer and Disposal

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may



be possible for someone to retrieve and reuse the data by means of special software.



To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the **Samsung Customer Care Center** for details.





Important! Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

No reproduction in whole or in part allowed without prior written approval. Specifications



and availability subject to
change without notice.
[070115]

End User License Agreement for Software (EULA)

The EULA for this device is
found in the Gear Manager
application, which is required
for operation of your device.
You may also access this
EULA at:

- [www.samsung.com/us/
Legal/SamsungLegal-EULA-
GEAR](http://www.samsung.com/us/Legal/SamsungLegal-EULA-GEAR)



Index

B

Battery Use & Safety 26

C

Care and Maintenance 42

D

Display / Touch-Screen 38

F

FCC Notice and Cautions 72



G

GPS 40

H

Health and Safety Information

4





O

Operating Environment 61

Other Important Safety

Information 74

R

Responsible Listening 50

**Restricting Children's Access
to Your Mobile device 71**

S

**Samsung Mobile Products and
Recycling 15**

**Smart Practices While Driving
20**

Standard Limited Warranty 82

