


Attachment 8.


- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information

* Diagonal dimension of Display and device




* Distance between BT/WIFI/GPS/Ant+ Antenna and edge



SAR Test Setup Photographs

■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 8 mm from the EUT]

■ Test Setup Photo (Left)



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Left)



[Distance of 4 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 9 mm from the EUT]

■ Test Setup Photo (Left) Keyboard



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Left) Keyboard**



[Distance of 4 mm from the EUT]

■ **Test Setup Photo (Corner)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Corner)**



[Distance of 6 mm from the EUT]