


## Antenna and Device Information


\* Distance between Main antenna and edge

Front View




\* Distance between Main antenna and edge

Front View




\* Distance between Bluetooth & WLAN antenna and edge

Front View




\* Distance between Bluetooth & WLAN antenna and edge

Front View




\* Diagonal dimension of LCD and device

Front View




\* Placement of each antenna

Front View




## SAR Test Setup Photographs

■ Test Setup Photo (Body All)




■ Test Setup Photo (Rear)




[Distance of 0 mm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 6 mm from the EUT]

■ Test Setup Photo (Rear)




[Distance of 15 mm from the EUT]

■ Test Setup Photo (Left )



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Top)



[Distance of **0 mm** from the EUT]

■ **Test Setup Photo (Top)**




**[Distance of 6 mm from the EUT]**

■ **Test Setup Photo (Top)**




**[Distance of 20 mm from the EUT]**


■ **Test Setup Photo (Keyboard cover)**



■ Spacer (6 mm)



■ Spacer (15 mm)



■ Spacer (20 mm)

