


Antenna and Device Information


* Distance between Main antenna and edge

Front View




* Distance between Main antenna and edge

Front View




* Distance between Bluetooth & WLAN antenna and edge

Front View




* Distance between Bluetooth & WLAN antenna and edge

Front View




* Diagonal dimension of LCD and device

Front View




* Placement of each antenna

Front View




SAR Test Setup Photographs

■ Test Setup Photo (Body All)




■ Test Setup Photo (Rear)




[Distance of 0 mm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 6 mm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 15 mm from the EUT]

■ Test Setup Photo (Left)



[Distance of 0 mm from the EUT]

■ Test Setup Photo (Top)



[Distance of **0 mm** from the EUT]

■ Test Setup Photo (Top)




[Distance of 6 mm from the EUT]

■ **Test Setup Photo (Top)**




[Distance of 20 mm from the EUT]


■ **Test Setup Photo (Keyboard cover)**



■ Spacer (6 mm)



■ Spacer (15 mm)



■ Spacer (20 mm)

