



## Antenna and Device Information


\* Placement of each antenna




\* Distance between Main antenna and edge



\* Distance between Main antenna and edge




\* Distance between Bluetooth & WLAN antenna and edge




\* Distance between Bluetooth & WLAN antenna and edge

Front View



\* Diagonal dimension of LCD and device

Front View




## SAR Test Setup Photographs

■ **Test Setup Photo (Body All)**



■ Test Setup Photo (Rear)



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Top)**




**[Distance of 0 mm from the EUT]**

■ Test Setup Photo (Left)




[Distance of 0 mm from the EUT]

■ Test Setup Photo (Rear) (Keyboard cover)



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Rear)**



**[Distance of 14 mm from the EUT]**

■ **Test Setup Photo (Top)**




**[Distance of 20 mm from the EUT]**

■ Test Setup Photo (Rear) (Keyboard cover)



[Distance of 14 mm from the EUT]

■ Test Setup Photo (Rear)




[Distance of 6 mm from the EUT]

■ Test Setup Photo (Top)




[Distance of 6 mm from the EUT]

■ Test Setup Photo (Rear) (Keyboard cover)



[Distance of 6 mm from the EUT]

■ **Test Setup Photo (Top) (Keyboard cover)**



**[Distance of 0 mm from the EUT]**

■ Spacer

