




2.2. Return Loss & VSWR Test

Samsung Antenna Lab has a system that can measure VSWR using RTS60 chamber and ZNB8 network analyzer. In order to measure the VSWR of each antenna, the antenna lab connects the coaxial cable to the point in contact with the antenna on the main board. The VSWR is measured through the coaxial cable connected in the set. At this time, the SM-X626B is assembled in the same state as the user environment.



3. Radiation Pattern Test

Antennas tested for Gain and Efficiency must be assembled into the enclosure and tested in the fully assembled and operating SM-X626B tablet. The antenna is tested in free space in the anechoic chamber in the H, E1 and, E2 planes. The radiation patterns are measured at the center of transmit and receive bands.



5. Antenna Info

Antenna Type : Metal ANT

