



MOBILE ENHANCEMENT

World Wide Web
<http://www.samsungmobile.com>

Printed in Korea
Code No.:GH68-xxxxxA
01/2008. Draft



 Bluetooth® Headset
WEP700
MOBILE ENHANCEMENT

English

English	1
----------------------	----------

Contents

Safety and usage information	2
Your headset overview	3
Charging the headset	4
Turning the headset on or off	4
Understanding various modes.....	5
Pairing with your Bluetooth phone.....	5
Wearing the headset	6
Warranty and parts replacement	8
Correct disposal of this product	9
Specifications.....	10

Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide. Bluetooth QD ID: B012977



Safety and usage information

- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorised service centre to repair it or replace the battery.
- When using your headset while driving, follow local regulations in the country or region you are in.
- Avoid storage at high temperatures (above 50° C/122° F), such as in a hot vehicle or in direct sunlight, as this can damage performance and reduce battery life.
- Do not expose the headset or any of its supplied parts to rain or other liquids.



At very high volumes, prolonged listening to the headset can damage your hearing.



Your headset overview



If your headset responds slowly, stops responding, or freezes, press the reset button on the back of the headset with a pointed tool.



Charging the headset

Put the adapter into the jack on the headset and into the electrical outlet.

Charge the headset until the red indicator light turns blue.



Do not attempt to charge the headset with anything other than the adapter provided.



The headset is available while charging. However, we recommend you to use the headset after charging is complete.



Turning the headset on or off

To turn the headset on, press and hold the Multi-function button until the blue indicator light flashes 4 times.

To turn the headset off, press and hold the Multi-function button until both blue and red indicator lights flash.



Understanding various modes

- **Standby mode:** The headset is waiting for a call. The blue indicator light flashes every 3 seconds.
- **Active mode:** The headset has a call in progress. The blue indicator light flashes every 8 seconds.
- **Pairing mode:** The blue indicator light stays lit. You can discover and connect to your headset on your phone.
- **Low battery mode:** There is less than 10% of battery power left. The red indicator light flashes. You must recharge the battery.



Pairing with your Bluetooth phone

- 1 Enter Pairing mode.
 - Turn off your headset and press and hold the Multi-function button until the blue indicator light remains lit after blinking.
 - If you turn it on for the first time, it proceeds into Pairing mode immediately.
- 2 Search for and pair with your phone according to your phone's user guide. (Bluetooth PIN: 0000, 4 zeros)

- If the pairing is successful, the blue indicator light will flash 10 times rapidly before entering Standby mode.
- If the blue indicator light remains lit, retry pairing.



When the headset and the phone are paired, the headset attempts to reconnect automatically each time it turns on. Otherwise, press the Multi-function button to reconnect.



Wearing the headset

Wear the headset on your ear. In general, you will get better performance when there are no obstructions (including parts of your body) between the headset and the phone.



Depending on what ear you are going to wear the headset, simply adjust the ear hook accordingly.



▲ Left



▲ Right



Using call features

Some features may not be supported by your phone.

In Standby mode

Press the Multi-function button to:

- Answer an incoming call
- Redial the last number called

Press and hold Multi-function button to:

- Make a voice-activated call
- Reject an incoming call

Press and hold [+] and [-] at the same time to turn the indicator light on or off.

In Active mode

Press the Multi-function button to:

- End a call
- Transfer a call from the phone to the headset

Press and hold Multi-function button to:

- Place a call on hold
- Answer a second call
- Retrieve a call on hold

Press [+] or [-] to adjust the volume.

Press and hold [+] or [-] to turn the microphone off or on.



Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase. (Depending on your country, the length of warranty may vary.)

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation modification, or repair by unauthorised third parties
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorised third parties voids any warranty



Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



Specifications

Item	Specifications and description
Version	Bluetooth 2.0 or earlier
Profile	Headset Profile, Hands-Free Profile
Operating range	Up to 30 feet (10 metres)
Maximum Standby time	Up to 80 hours*
Maximum Active time	Up to 5 hours*

* Depending on the phone type and usage, the actual time may vary.



Safety approvals

FCC

FCC ID: A3LWEP700

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

Industry Canada

IC ID: 649E-WEP700

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term “IC:” before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

Bluetooth

The Bluetooth[®] word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Samsung is under license. Other trademarks and trade names are those of their respective owners.

UL certified travel adapter

The travel adapter for this headset has met UL 1310 safety requirements. Please adhere to the following safety instructions per UL guidelines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN THE U.S.A., USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET.

Cautions

Cautions

Changes or modifications made in the radio phone, not expressly approved by Samsung, will void the user's authority to operate the equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone. Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.



Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase.

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation modification, or repair by unauthorized third parties
- The responsibility of Samsung products shall be limited to the repair or replacement of the product at its sole discretion
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories

- Samsung is not liable to for any incidental or consequential damages arising from the use or misuse of any Samsung product
- This warranty gives you specific rights and you may have other rights which vary from area to area
- Unless otherwise instructed in the User Guide, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the unit, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorized third parties voids any warranty



Correct disposal of this product

(Waste Electrical & Electronic Equipment)



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.