




Ant3 Freq. 5280 MHz:




Ant3 Freq. 6175 MHz:




Ant3 Freq. 5500 MHz:




Ant3 Freq. 6475 MHz:




Ant3 Freq. 6700 MHz:



Ant3 Freq. 5820 MHz:



Ant3 Freq. 7000 MHz:



Ant3 Freq. 5887 MHz:

