





Buttons expanded view




1 Mode switch



Slide to switch between speaker and headphone modes.

*Slide to headphone mode when not in use to prevent drainage of internal battery in speaker mode.

2 Power button



Pairing devices:

Press and hold power button until power on prompt is heard. Search for new Bluetooth device and select X-mini™ EVOLVE 2. The connected prompt is heard once the headphone speaker is paired successfully.

*If pairing is unsuccessful, switch off and on X-mini™ EVOLVE 2 to reattempt.

*If sound continues to be played through the connected device's built-in speakers, set Bluetooth to preferred audio settings.

*AVRCP must be supported by the connected device in order to use the controls.

XConnect function:


Connect the first device to X-mini™ EVOLVE 2 and disconnect once connection is successful. Connect another device to X-mini™ EVOLVE 2, and reconnect the first device. Connected prompts are heard each time the devices are paired successfully with the speaker.

*A maximum of two devices can be paired to a X-mini™ EVOLVE 2.

*Pause music on one device before playing music from the other device.

*Music will play from one device each time.

3 Volume buttons



Volume control:

Press and hold ▲ volume button to increase volume

Press and hold ▼ volume button to decrease volume

Music control:

Press ▲ volume button once to change to next song

Press ▼ volume button once to change to previous song

4 Microphone



Redial: Press power button twice

Volume up: Press ▲ button

Volume down: Press ▼ button


Answering call: Press power button once

Rejecting call: Press and hold power button for 2s

Mute: Press ▲ volume and ▼ volume buttons together

*Functions and indication tones may vary between devices.

5 LED light



*Audio output gets softer and a warning tone is heard when the battery level of the speaker is low. Recharge before use.