


BATTERY CAMERA

Content

	02
Overview	04
Parameters	06
Our Camera	07
Our Camera	11
	15
Service	17

Box, please check the following pictures to see if they are complete.



roduction

Battery Powered and RTOS System

a built-in PIR module and RTOS system the battery camera can last for 3 months if it had been triggered 20 times per day after a full charging.

Completely Wireless:

Doesn't need any cable for line power or network.

Excellent Clarity:

104*1296) Ultra HD Resolution.



Color Night Vision:

hardware has the built-in IR LEDs and spotlights that allow you to capture a color image even at night.

orage:

port local storage and cloud storage.

Overview



- | | | | |
|----------------------|-----------------------|--------------------------|----------------|
| 5 Lens | 9 Power Button | Charging Indicator | Description |
| 6 Microphone | 10 Power Input | Solid red | Battery full |
| 7 Micro SD Card Slot | 11 Reset Button | Solid blue | Charging |
| 8 Speaker | 12 Charging Indicator | Flashing indicator light | Charging error |

Status LED	Description
Slow blinking red	Ready to connect
Fast blinking red	Disconnected
Slow blinking blue	Connection successful
Solid blue	The connection is successful
Flashing blue and red alternately	A firm connection has been established

Charging Indicator	Description
Solid red	Battery is fully charged
Solid blue	Charging in progress
Flashing indicator light	Charging error or fault

Basic Parameters

Active Pixels	2304*1296	Storage
Clarity Resolution	3MP	Wi-Fi
FOV(D)	122°	Network Security
Lens	3.5mm@F2.0	Battery Capacity
IR LED	8m	Item Weight
Spotlights	8m	Product Dimensions
Audio	MIC/Speaker	Charging Power
PIR	8m(100°)	Mounting Type
Water Proof	IP66	Working Temp
Charging Temp	0~45℃	

Set Up Your



Step 1 **Downl**

Download the Tuya Smart or Smart Life App from the App Store or Google Play, or by scanning the QR code




Step 2 Connect it to the

1. Sign up an App account, go to the App homepage, tap Add and select the smart camera(Wi-Fi).




 Please follow the prompts of the App to allow relevant permission otherwise it will affect the addition and use of the device.

2. Press and hold the power button for 3s until the status LED is slow blinking red or heard "Waiting to receive the wireless configuration"




⚠ Please choose a 2.4GHz Wi-Fi, the camera does not support the 5GHz Wi-Fi.

Reset the device
If the SSID of your home Wifi have been changed, you need to reconfigure the network. Please hold the reset button for 5-6 seconds until you heard "reset successfully", then take the prompts to add the device again




⚠ When adding devices, please make the camera and mobile phone connect to a same Wi-Fi router.

3. Please click Next, select a stable network and enter a password. The camera of the device scans the QR code generated by the mobile phone, keeps a distance of 15 to 20cm and does not move until the sound of "Di" is heard, and finally follows the steps on the App to complete the addition.




Mount Your Camera


Select a location
The camera can be mounted on a wall or ceiling. Choose a spot where you can get the desired view.
Make sure to pick a place within range of your home network. Please try streaming video before you mount your camera.
We recommend hanging it 2.5m (8.2 ft) above the ground and maintaining an angle of about 25 degrees from the horizontal ground.




To mount the Camera on the wall:




Step 1
Align the mounting plate and mark the four circles where the holes need to be drilled.



Step 2
Drill four holes above the four marked circles.



Step 3
Insert four anchors into the holes and use the screws to affix the bracket over the anchors.




Step 4
Align the hole at the bottom of the camera with the mounting bracket, and turn the camera clockwise to fix the camera to the mounting bracket. Rotate the camera to adjust the view and check it using the live stream which you can access in the App.

To mount the Camera on the ceiling:

Please follow the steps 1-6 to secure the camera onto the ceiling.

How to remove Your Camera:
Hold the main body of the camera, then rotate anticlockwise to remove the camera from the mounting bracket.



Notice

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Siren function

After the alarm function is turned on in the App, the camera will sound an audible alarm after detecting an event. If you do not need it, you can turn off this function in the App.

App device settings

When the device parameters are set in the App, they will only take effect after the device goes to sleep and wakes up next time. For example, you turn on the Siren function in the App settings, which can only be turned on after the device wakes up next time.

CAUTION

Risk of fire or explosion if the battery is replaced by an incorrect type.
Avoid replacement of a battery with an incorrect type that can defeat a safeguard.
Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting off a battery, that can result in an explosion.
Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; Do not leave a battery subjected to the extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Customer Service

Warranty
12-month Limited Warranty