

QUICK INSTALLATION GUIDE



tend

01

Download the Tend Baby app to your iOS or Android device.



02

Find the perfect spot for your new Kodak Baby Monitoring System & plug it into an outlet using the enclosed power adapter.



03

Press the power button on the right side of the Base Unit to turn it on. You'll hear "power on".

04



Wait up to two minutes for the camera to go into setup mode. When ready, the LED lights on the right side of the Camera will blink and alternate between orange and green (pull the camera towards you to see the LED lights).



05

Go to the Wi-Fi settings on your mobile device and connect to the Wi-Fi network labeled CFH-BVA10XXXX (last 4 digits of the MAC ID).



06

Launch the Tend Baby app to allow the camera and your mobile device to sync. Follow on-screen instructions to complete Camera and App setup.



07

The Base Unit and the Parent Unit come pre-paired for your convenience. Simply press the power button on the right side of the Base Unit to turn it on, then press the circular power button located in the middle of the handheld Parent Unit. You'll hear "power on".

For detailed instructions, visit kodak.tendinsights.com/setup

Kodak

Baby Monitoring System

CFH-BVA10

WE'RE HERE TO HELP

Learn more about the KODAK Baby Monitoring System and Tend Baby app at kodak.tendinsights.com

The Kodak trademark and trade dress are used under license from Kodak

Apple, iPad, and iPhone are trademarks of Apple, Inc.

Android is the trademark of Google Inc.

© 2015 Tend Insights, Inc. All rights reserved.

Made in China

PACKAGE CONTENTS

BASE UNIT WITH 180° WI-FI VIDEO CAMERA
PARENT UNIT (BATTERIES INCLUDED)
BASE UNIT COVER
POWER ADAPTER FOR PARENT UNIT
POWER ADAPTER FOR BASE UNIT
QUICK INSTALLATION GUIDE

U.S. REGULATORY NOTICES

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

LIMITED ONE YEAR MANUFACTURER'S WARRANTY

Tend Insights, Inc. dba Tend ("Tend") will repair or replace (at our discretion) your camera unit free of charge (except for shipping cost) for 12 months from the date of purchase, if unit is determined to be defective. The customer should return the defective unit to the original place of purchase first, based on its return or refund policy. If the original vendor's return/refund policy has expired and this unit is still within the limited manufacturer's warranty, customers can call 1-888-733-9123 or email us at support@tendinsights.com to get an RMA ID and shipping instructions. Camera must be shipped with proof of purchase. Customer will need to pay for shipping of the defective camera to Tend. Tend will be responsible for shipment of replacement camera. In the absence of a purchase receipt, the warranty period shall be 12 months from the date the camera was manufactured.

In no event shall Tend be liable for any special, incidental, or consequential damages for breach of this or any other warranty, expressed or implied, whatsoever.

The detailed terms and conditions can be found on kodak.tendinsights.com.