



AwoX StriimLIGHT WiFi Color

SLC-W13 E26

User manual

Mode d'emploi

Benutzerhandbuch

Guía del usuario

Guida di utilizzo

Návod pro uživatele

Brugsanvisning

Gebruiksaanwijzing

Käyttöopas

Használati útmutató

Bruksanvisning

Podręcznik użytkownika

Manual do Utilizador

Руководство пользователя

Användarhandbok

Navodila za uporabo

Kullanıcı kılavuzu

دليل المستخدم

EN	Full user guide on CD-ROM and www.awox.com
FR	La version intégrale de ce mode d'emploi est fournie sur le CD-ROM.
IT	La guida utente completa si trova sul CD-ROM.
DE	Das vollständige Benutzerhandbuch befindet sich auf der CD-ROM.
ES	La guía del usuario complete se encuentra en el CD-ROM.
CS	Úplný návod pro uživatele naidete na CD-ROMu.
DK	Komplet brugerveiledning findes på CD-ROM'en.
NL	Integrale handleiding op cd-rom en www.awox.com .
FI	Täydellinen käyttöopas on CDRom-levyllä.
HU	A teljes használati útmutató a CD-lemezen található.
NO	En komplett brukerveiledning finnes på CD-ROM'en.
PL	Pełny podręcznik użytkownika znajduje się na płycie CD.
PT	O Guia do Utilizador Completo encontra-se no CD-ROM.
RU	Полное руководство пользователя находится на CD-ROM.
SE	Hela Användarhandboken finns på cdrom-skivan.
SL	Celotna navodila za uporabo so na CD-ROM-u.
TR	Tam kullanıcı kılavuzu CD-ROM üzerindedir.
AR	النسخة الكاملة من دليل المستخدم متوفرة على القرص المضغوط.

AwoX StriimLIGHT WiFi Color

Quick-start guide

Contents

Contents.....	2
Getting started with AwoX StriimLIGHT WiFi Color	3
Before you begin.....	4
Starting your product.....	5
AwoX Striim CONTROL setup	8
More information on CD-ROM and AwoX Web site	8

© 2013 AwoX. All rights reserved. StriimLIGHT, AwoX, the AwoX logo and other AwoX and AwoX Striim marks are owned by AwoX. iPhone, iPad, and iPod are trademarks of Apple, Inc., registered in the U.S and other countries. Android is a trademark of Google Inc. DLNA and DLNA CERTIFIED are trademarks and/or service marks of Digital Living Network Alliance. All other trademarks are the property of their respective owners. Smartphone or tablet device sold separately. This is a non-contractual document. Read provided safety information before using this product.

Rev 01 (EU)

Getting started with AwoX StriimLIGHT WiFi Color

Welcome

Congratulations and thank you for choosing the AwoX StriimLIGHT WiFi Color speaker light. This innovative music player contains both a full-color LED light bulb and an audio speaker, giving you a great way to listen to music from nearly any source anywhere you can plug in a light bulb! Use several Striim® WiFi products to create zones in full stereo around the house.

- A fun and easy way to play music from many sources, including your Apple iOS™ or Google Android™ smartphone or tablet, PC or Mac⁽¹⁾, home servers, and the Internet
- Access to hundreds of Internet radio stations⁽²⁾
- Use the free AwoX media player software for your iPhone®, iPad®, iPod touch®, or Android smartphone.⁽³⁾

⁽¹⁾ Requires DLNA-compatible media server. ⁽²⁾ Requires Internet connection.

⁽³⁾ Download the free AwoX Striim CONTROL software for your Apple or Android OS device.

What's in the box

- StriimLIGHT Color light bulb with speaker
- Remote control (with battery)
- Mini CD-ROM with complete user guide and AwoX StriimSERVER software for PC and MAC.
- This guide
- Safety and warranty leaflet

What else you need

- Wi-Fi Internet access
- A supported smartphone. or computer with StriimCONTROL for Windows or Mac software installed (available for free on www.awox.com)

This document only describes how to use the smartphone. software.

Before you begin

1. Start by downloading the free AwoX media player for your device:

**Apple
iPhone.
iPad. iPod
touch**



Download and install AwoX Striim CONTROL™ software from the App Store.


**Google
Android
devices**



Download and install AwoX Striim CONTROL™ software from the Google Play Store.

2. On your Apple or Android device, make sure Wi-Fi is turned on and then use the device's settings to connect to your home network.


StriimLIGHT WiFi color presentation




Starting your product

Screw your StriimLIGHT WiFi Color device into a light socket and turn on the power. Wait a few moments for the device to startup. At first, a blue light will blink slowly. After starting, this light remains blue continuously.

StriimLIGHT WiFi Color remote control



Changing the remote control battery



1. Slide and lift off cover from back of remote control.
2. Use the tip of a pen to push back the tab in the corner.
3. Press bottom of battery to lift from slot.
4. To replace the battery, place the bottom of the battery in first and push until it clicks into position.

If your Internet router supports WPS

WPS is a feature that enables you to add new Wi-Fi devices to your network at the touch of a button. If your Internet router supports WPS, simply press the WPS button on the router and then press the WPS button on your StriimLIGHT WiFi Color device. The two devices will recognize each other automatically and you may begin using the AwoX Striim CONTROL application right away. Otherwise, the installation wizard runs as described in the next section.

Note: Do not use any kind of electrical dimmer switch other than the provided remote control.

AwoX Striim CONTROL setup

1. After downloading the application, tap on the launcher icon to run **AwoX Striim CONTROL**.
2. If StriimCONTROL does not detect a StriimLIGHT color device in your network, the setup wizard starts the first time you launch the application.
3. Choose to install **AwoX StriimLIGHT WiFi**.
4. The wizard guides you through all the steps for connecting your AwoX StriimLIGHT WiFi Color device to your local network to begin playing your music.



More information on CD-ROM and AwoX Web site

AwoX Striim Control offers many features enabling you to get the most out of your AwoX products. Complete instructions for using the free AwoX software are provided in Adobe PDF® format on your AwoX StriimLIGHT WiFi Color CD-ROM and on www.awox.com.

AwoX

Important safety and warranty information



1. ENGLISH

IMPORTANT SAFETY INSTRUCTIONS WARNING: ELECTRIC SHOCK HAZARD

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains a transmitter module. Category code: CAN ICES-3(B)/NMB-3(B)

Please read these instructions — Keep these instructions — Follow all instructions carefully — Heed all warnings

- Unplug the product from the electrical source before cleaning it with a dry towel.
- Respect all manufacturer instructions when installing the product.
- Place the product so that it is stable, as any fall may damage the product or cause bodily harm.
- Do not use the product near any water source and do not get it wet.
- Do not block any openings on the product. Never push any objects into the openings or slots on the product. Doing so may create an electric shock or fire hazard. Maintain sufficient distance around your product for sufficient ventilation.
- Do not use the product near a heater, stove, or any other source of heat.
- Avoid stepping on the power cord or pinching it.
- Only use accessories specifically recommended by the manufacturer.
- For best protection against lightning, unplug the product from its power source in the event of a storm.
- The product must be repaired if it is damaged, if liquid is spilled on the product, if objects fall on the product, if the product is exposed to rain or humidity, if the product is not working properly, or if it has been dropped.
- Repairs must be performed by a qualified technician.
- For lamps with a weight significantly higher than that of the lamps for which they are a replacement, attention should be drawn to the fact that the increased weight may reduce the mechanical stability of certain luminaires and lamp holders and may impair contact making and lamp retention.
-  Symbol indicates lamp is not suitable for dimming.
- The LED used in these products have been tested according to IEC/EN62471, the retinal blue light hazard or thermal hazard was classified as exempt group when LED lighted.
- Risk of swallowing batteries! The remote control contains a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.
- CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
-  The marked item can be hot and should not be touched without taking care.

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, NOT EXPOSE THIS PRODUCT TO WATER, RAIN, OR HUMIDITY.
THE MAINS SWITCH AND ALL-POLE CIRCUIT BREAKER ARE NOT PROVIDED WITH THE APPARTUS, THE INSTALLATION SHALL BE CARRIED OUT IN ACCORDANCE WITH ALL APPLICABLE INSTALLATION RULES.**

AwoX hardware product limited warranty

AwoX warrants that your AwoX hardware product shall be free from defects in material and workmanship for the length of time set forth on the product packaging and/or in the product documentation, beginning from the date of purchase. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights, and you may also have other rights that vary under local laws.

Remedies

AwoX's entire liability and your exclusive remedy for any breach of warranty shall be, at AwoX's option, (1) to repair or replace the hardware, or (2) to refund the price paid, provided that the hardware is returned to the point of purchase with a copy of the sales receipt or dated itemized receipt. Shipping and handling charges may apply except where prohibited by applicable law. AwoX may, at its option, use new or refurbished or used parts in good working condition to repair or replace any hardware product. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer or for any additional period of time that may be applicable in your jurisdiction.

This warranty does not cover problems or damage resulting from (a) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (b) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (c) use of consumables, such as replacement batteries, not supplied by AwoX except where such restriction is prohibited by applicable law.

How to Obtain Warranty Support

Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase. However, this period of time may vary depending on where you purchased your product. Please check with AwoX or the retailer where you purchased your product for details.

Limitation of Liability

AWOX SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF AWOX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some jurisdictions do not allow the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Duration of Implied Warranties

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

National Statutory Rights

Consumers have legal rights under applicable national legislation governing the sale of consumer goods. Such rights are not affected by the warranties in this Limited Warranty.

No Other Warranties

No AwoX dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

Warranty Periods

The product is guaranteed for a period of one (1) year. Please note that in the European Union, any warranty period less than two years shall be increased to two years.

Defective products, exchange procedure

Please note that in the European Union, any warranty period less than two years shall be increased to two full years.

Battery warning

This product includes a remote control with a rechargeable Polymer Lithium-Ion battery. Make sure you respect polarity (+/-) when inserting the battery into the unit.

© 2014 AwoX. All rights reserved. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by AwoX is under license. AwoX, the AwoX logo and other AwoX marks are owned by AwoX. Other trademarks and trade names are those of their respective owners. Smartphone or tablet device sold separately Product images and photos are non-contractual.

2. FRANCAIS

CONSIGNES DE SÉCURITÉ IMPORTANTES MISE EN GARDE : RISQUE D'ÉLECTROCUTION

Cet appareil contient un module émetteur. Code catégorie : CAN ICES-3(B)/NMB-3(B)

Veillez lire attentivement ces consignes de sécurité. — Veuillez les conserver. — Suivez toutes ces consignes à la lettre. — Tenez compte de toutes les mises en garde.

- Pour l'entretien, débranchez le produit, puis nettoyez-le à l'aide d'un chiffon sec.
- Pendant l'installation du produit, respectez toutes les instructions fournies par le fabricant.
- Veillez à ce que le produit soit bien stable. Dans le cas contraire, il risque de tomber et d'être endommagé ou de blesser les utilisateurs.
- N'utilisez pas le produit près d'un robinet ou d'un point d'eau et ne le mouillez pas.
- Ne bouchiez pas les ouvertures. N'insérez jamais d'objets dans les ouvertures ou les fentes du produit. Dans le cas contraire, il existe un risque d'électrocution ou d'incendie. Pour permettre une aération suffisante, ne placez pas d'objet contre le produit.
- N'utilisez pas le produit à proximité d'un radiateur, d'une cuisinière ni de toute autre source de chaleur.
- Ne marchez pas sur le câble électrique et ne l'écrasez pas.
- Utilisez uniquement les accessoires recommandés par le fabricant.
- En cas d'orage, débranchez le produit de l'alimentation électrique.
- Si le produit est endommagé ou mouillé, si des objets tombent dessus, s'il est exposé à la pluie ou à l'humidité, s'il ne fonctionne pas correctement ou s'il tombe par terre, faites-le réparer.
- Les réparations doivent impérativement être effectuées par un technicien qualifié.
- ATTENTION : si l'ampoule StrimLIGHT s'avère considérablement plus lourde que l'ampoule initialement installée dans le luminaire, cette différence de poids peut engendrer une certaine instabilité au niveau du luminaire. De plus, le contact entre l'ampoule et la douille peut être réduit et l'ampoule peut ne pas rester fixée dans la douille.
-  Ce symbole indique que l'ampoule n'est pas compatible avec les gradateurs.
- L'ampoule à LED utilisée appartient au groupe 1 selon la norme IEC/EN 62471 ; éviter tout contact oculaire direct avec le faisceau lumineux et éviter de regarder directement l'ampoule de manière prolongée.
- ATTENTION : il existe un risque d'explosion si une pile inadéquate est utilisée. Utiliser uniquement une pile identique ou équivalente.
- Risque d'ingestion des piles ! La télécommande contient une pile bouton suffisamment petite pour être avalée. Tenir cette pile hors de portée des enfants en permanence ! En cas d'ingestion, cette pile peut entraîner des blessures graves, voire la mort. Des brûlures internes graves peuvent apparaître dans les deux heures suivant l'ingestion.

- ⚠ Ce symbole indique que l'objet peut être chaud et doit être manipulé avec prudence.

MISE EN GARDE : POUR RÉDUIRE LE RISQUE D'INCENDIE ET D'ÉLECTROCUTION, N'EXPOSEZ PAS CE PRODUIT À L'EAU, À LA PLUIE NI À L'HUMIDITÉ.

Garantie limitée de l'appareil AwoX

AwoX garantit les appareils AwoX contre tout défaut de matériel et de fabrication pendant la durée indiquée sur l'emballage des produits et/ou dans la documentation fournie avec les produits. Cette garantie prend effet à la date de l'achat. Sauf lorsque la loi en vigueur interdit cette disposition, la présente garantie ne peut être transférée ; elle s'applique uniquement à l'acheteur initial. La présente garantie énumère vos droits légaux spécifiques ; selon la législation locale, vous pouvez bénéficier de droits supplémentaires.

Recours

En cas de défaut de matériel ou de fabrication, la responsabilité d'AwoX et votre unique recours seront les suivants, à la discrétion d'AwoX : (1) réparation de l'appareil ou échange ; ou (2) remboursement du prix d'achat, à condition que l'appareil soit retourné au point de vente avec une photocopie du ticket de caisse ou un reçu détaillé indiquant la date de l'achat. Les frais de port et de manutention pourront être à votre charge, sauf lorsque la loi en vigueur l'interdit. Pour la réparation ou l'échange de tout appareil, AwoX peut, à sa discrétion, utiliser des pièces neuves, remises à neuf ou usagées en bon état de fonctionnement. En cas d'échange, le nouvel appareil sera garanti pendant la durée restante du contrat initial ou pendant trente (30) jours, si la durée restante est inférieure à ce délai. Le cas échéant, il sera garanti pendant toute durée supplémentaire fixée par la réglementation locale.

La présente garantie ne couvre pas les problèmes ou dégâts dus à : (a) un accident, un mauvais traitement, une mauvaise installation, ou une réparation, une modification ou un démontage non autorisés ; (b) une mauvaise utilisation ou un mauvais entretien, une utilisation non conforme au mode d'emploi ou un branchement sur une tension électrique inadaptée ; ou (c) l'utilisation de consommables, comme les piles de rechange, non fournis par AwoX, sauf lorsque ladite restriction est interdite par la loi en vigueur.

Comment émettre une réclamation ?

Pendant les trente (30) premiers jours suivant l'achat, les réclamations jugées valables sont généralement traitées par le biais du point de vente. Cependant, cette durée peut varier en fonction des revendeurs. Contactez AwoX ou votre point de vente pour plus de précisions.

Responsabilité limitée

AWOX NE SAURAIT EN AUCUN CAS ÊTRE TENU DE VERSER DES DOMMAGES ET INTÉRÊTS PARTICULIERS, INDIRECTS OU ACCESSOIRES, ENTRE AUTRES POUR LA PERTE DE BÉNÉFICE, DE REVENUS OU DE DONNÉES (QU'ELLE SOIT DIRECTE OU INDIRECTE) OU LA PERTE COMMERCIALE EN RAISON DE LA RUPTURE DE TOUTE GARANTIE EXPRESSE OU TACITE CONCERNANT VOTRE PRODUIT, MÊME SI AWOX A ÉTÉ INFORMÉ DE LA POSSIBILITÉ DESDITS DOMMAGES. Certaines juridictions interdisent l'exclusion ou la restriction des dommages et intérêts particuliers, indirects ou accessoires. Par conséquent, les restrictions susmentionnées peuvent ne pas s'appliquer dans votre cas.

Durée des garanties tacites

SAUF SI LA LOI EN VIGUEUR L'INTERDIT, TOUTE GARANTIE TACITE OU TOUTE CONDITION DE VALEUR MARCHANDE OU DE POSSIBILITÉ D'UNE UTILISATION PARTICULIÈRE DE CET APPAREIL SONT VALABLES UNIQUEMENT POUR LA DURÉE DE LA GARANTIE LIMITÉE DU PRODUIT. Certaines juridictions interdisent de limiter la durée des garanties tacites. Par conséquent, les restrictions susmentionnées peuvent ne pas s'appliquer dans votre cas.

Droits définis par les lois nationales

Les lois nationales relatives à la vente de biens de consommation accordent certains droits aux acheteurs. Les présentes garanties limitées n'ont aucun impact sur ces lois.

Aucune autre garantie

Aucun revendeur, agent ou employé AwoX n'est autorisé à modifier, prolonger ou compléter la présente garantie.

Durée de garantie

Le produit est garanti (1) an, sauf dans l'Union européenne, où la durée minimale des contrats de garantie est obligatoirement de deux années complètes.

Produits défectueux, procédure d'échange

Dans l'Union européenne, la durée minimale des contrats de garantie est obligatoirement de deux années complètes.

Mise en garde concernant les piles

Ce produit est fourni avec une télécommande alimentée par une pile lithium. Respectez bien la polarité (+/-) lorsque vous insérez les piles dans l'appareil.

© 2014 AwoX. Tous droits réservés. StrimLIGHT, StrimLIGHT mini, AwoX, le logo AwoX et les autres marques AwoX appartiennent à AwoX. La marque et les logos Bluetooth® appartiennent à Bluetooth® SIG, Inc. Toutes les autres marques déposées appartiennent à leurs détenteurs respectifs. Lecteur de musique non fourni avec l'appareil. Photos non contractuelles. Toutes les autres marques déposées appartiennent à leurs détenteurs respectifs.

3. ESPAÑOL

**INSTRUCCIONES DE SEGURIDAD IMPORTANTES
ADVERTENCIA: PELIGRO DE DESCARGA ELÉCTRICA**

Esta máquina contiene un módulo transmisor. Código de clase: CAN ICES-3(B)/NMB-3(B)

**Por favor, lea y siga atentamente estas instrucciones.
Guárdelas y preste atención a todas las advertencias.**

- Desconecte el producto de la fuente de alimentación eléctrica antes de limpiarlo con un trapo.
- Respecte todas las instrucciones del fabricante a la hora de instalar el producto.
- Coloque el producto de manera estable; cualquier caída podría dañarlo o causar daños físicos.
- No utilice el producto cerca de una fuente de agua o lugar húmedo.
- No obstaculice ninguna de las aperturas del producto. No introduzca ningún objeto en las aperturas o ranuras del producto; podría sufrir una descarga eléctrica o provocar fuego. Despeje los alrededores del producto para que haya suficiente ventilación.
- No utilice el producto cerca de ninguna estufa, calentador o cualquier otra fuente de calor.
- Evite pisar el cable o pellizcarlo.
- Utilice únicamente accesorios recomendados específicamente por el fabricante.
- Para proteger el producto de los rayos, desconéctelo de la fuente de alimentación eléctrica en caso de tormenta.
- Repare el producto si éste resulta dañado, si se derrama líquido sobre el mismo, si se le cae algún objeto encima, si queda expuesto a la lluvia o la humedad, si no funciona correctamente o si se ha caído.
- Las reparaciones debe realizarlas un técnico calificado.
- En el caso de bombillas con un peso significativamente mayor al de las bombillas que sustituyen, téngase en cuenta que el aumento de peso puede reducir la estabilidad mecánica de algunas luminarias y portalámparas y puede alterar el contacto o el anillo de retención de la bombilla.
- ⚠ Este símbolo indica que las bombillas no son aptas para lámparas con atenuador.
- El LED utilizado cuenta con la calificación 1 Group tras una evaluación de acuerdo con el estándar IEC/EN 62471; no deje la vista fija en el haz de luz y evite mirar la bombilla durante un tiempo prolongado de manera directa y fija.
- ATENCIÓN: riesgo de explosión si la pila no se sustituye por una adecuada; utilice las mismas pilas o de tipo equivalente.
- ¡Riesgo de ingestión! El mando a distancia consta de una pila de botón que puede ingerirse sin querer. Deje siempre la pila fuera del alcance de los niños. En el caso de ser ingerida, puede causar lesiones graves e incluso la muerte; puede producir quemaduras internas graves durante las dos horas siguientes a la ingestión.
- ⚠ Este símbolo indica que el objeto marcado puede estar caliente y no debe tocarse sin tomar precauciones.

ADVERTENCIA: PARA REDUCIR LOS RIESGOS DE INCENDIO O DESCARGA ELÉCTRICA, NO EXPONGA EL PRODUCTO AL AGUA, LLUVIA O HUMEDAD. EL INTERRUPTOR DE RED Y EL DISYUNTOR OMNIPOLAR NO SE SUMINISTRAN CON EL APARATO; LA INSTALACIÓN DEBERÁ REALIZARSE DE ACUERDO CON TODAS LAS NORMAS APLICABLES.

Garantía limitada para el hardware AwoX

AwoX garantiza este producto de hardware AwoX de defectos materiales y de mano de obra durante el periodo descrito en la caja del producto y/o su documentación, a contar desde la fecha de compra. Excepto cuando la ley lo prohíba, esta garantía no es transferible y queda limitada al comprador original. Esta garantía le otorga derechos legales específicos, además de aquéllos variables según las leyes locales.

Recursos

La responsabilidad total de AwoX y su recurso exclusivo por cualquier incumplimiento de la garantía será (a elección de AwoX): 1) reparar o sustituir el hardware o 2) devolver el importe pagado por el mismo, siempre y cuando el producto sea devuelto al punto de venta con una copia del recibo de compra o del recibo detallado y fechado. AwoX podrá aplicar costes de transporte o de porte excepto cuando la ley lo prohíba. AwoX puede, a su elección, utilizar tanto piezas nuevas, como recicladas o usadas siempre que éstas estén en buen estado para reparar o sustituir cualquier producto de hardware. Cualquier producto o pieza de sustitución quedará garantizado por el periodo restante de la garantía del producto original o treinta (30) días cualquiera que sea la duración o para cualquier periodo adicional aplicable en su jurisdicción.

Esta garantía no cubre problemas o daños producidos por 1) accidentes, abuso, uso indebido o cualquier reparación, modificación o desensamblado no autorizado; 2) funcionamiento o mantenimiento inadecuados, utilización no compatible con las instrucciones o conexión a una fuente de alimentación eléctrica inadecuada; o 3) utilización de consumibles, como baterías de repuesto no provistas por AwoX, siempre y cuando esta restricción no esté prohibida por la ley aplicable.

Obtención del servicio de garantía

Las reclamaciones por los artículos con una garantía válida serán gestionadas generalmente en el punto de venta durante los primeros treinta (30) días posteriores a la compra. Sin embargo, este periodo de tiempo puede variar en función del lugar de compra. Consulte con AwoX o en el punto de venta para más información.

Limitación de responsabilidad

AWOX NO SE RESPONSABILIZA DE NINGÚN DAÑO ESPECIAL, INDIRECTO, FORTUITO O CONSECUENTE, INCLUYENDO, PERO SIN LIMITARSE A, PÉRDIDAS DE BENEFICIOS, INGRESOS O DATOS (TANTO DIRECTOS COMO INDIRECTOS) O PÉRDIDAS COMERCIALES DEBIDAS AL INCUMPLIMIENTO DE CUALQUIER GARANTÍA EXPLÍCITA O IMPLÍCITA DE SU PRODUCTO, INCLUSO SI AWOX HA SIDO PREVENIDO DE LA POSIBILIDAD DE DICHOS DAÑOS. Algunas jurisdicciones no permiten la exclusión o limitación de daños especiales, indirectos, fortuitos o consecuentes, en cuyo caso la limitación o exclusión anterior no sería aplicable.

Duración de las garantías implícitas

EXCEPTO EN LOS CASOS PROHIBIDOS POR LA LEGISLACIÓN APLICABLE, CUALQUIER GARANTÍA O CONDICIÓN IMPLÍCITA DE COMERCIALIZACIÓN O IDEONIDAD PARA UN FIN DETERMINADO DE ESTE PRODUCTO DE HARDWARE QUEDA LIMITADA AL PERIODO DE LA GARANTÍA LIMITADA APLICABLE A SU PRODUCTO. Algunas jurisdicciones no permiten limitaciones de tiempo en la garantía, en cuyo caso la limitación anterior no sería aplicable.

Derechos legales específicos

Los consumidores tienen derechos legales específicos a la legislación nacional aplicable que rige la venta de bienes de consumo. Esta garantía limitada no afecta a dichos derechos.

Inexistencia de otras garantías

Ningún comerciante, agente o empleado de AwoX está autorizado a hacer modificaciones, extensiones o adiciones en esta garantía.

Duración de la garantía

Este producto tiene una garantía de un (1) año. En los países de la Unión Europea, la duración de la garantía es de dos (2) años.

Cambio de productos defectuosos

En los países de la Unión Europea, la duración de la garantía es de dos (2) años.

Advertencia sobre la batería

Este producto incluye un mando a distancia con una batería de litio. Asegúrese de respetar la polaridad (+/-) al introducir la batería en la unidad.

© 2014 AwoX. Todos los derechos reservados. StrimLIGHT, StrimLIGHT mini, AwoX, el logo de AwoX y otras marcas de AwoX son propiedad de AwoX. La palabra marca Bluetooth® y sus logos son propiedad de Bluetooth® SIG, Inc. Todas las demás marcas son propiedad de sus respectivos propietarios. El reproductor de música se vende por separado. Las fotos del producto no son contractuales.

1 Important

Important safety instructions

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings.
Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storm or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Not for totally enclosed luminaires.
- Not for emergency lighting.
- For lamps with weight significantly higher than that of the lamps for which they are a replacement, attention should be drawn to the fact that the increased weight may reduce the mechanical stability of certain luminaires and lamp holders and may impair contact making and lamp retention.
- **Battery usage CAUTION** - To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:
 - Install **all** batteries correctly, + and - as marked on the unit.
 - Do not mix batteries (**old** and **new** or **carbon** and **alkaline**, etc.).
 - Remove batteries when the unit is not used for a long time.
 - The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
 -  **WARNING**
DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD.
- The product/remote control may contain a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.
- If you suspect that a battery has been swallowed or placed inside any part of the body, seek immediate medical attention.
- When you change the batteries, always keep all new and used batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.
- Caution: Danger of explosion if battery is incorrectly replace. Replace with only the same or equivalent type.
- If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer.
- Do not ingest battery, chemical burn hazard.
- **Apparatus shall not be exposed to dripping or splashing.**
- **Do not place any sources of danger on the apparatus** (for example, liquid filled objects, lighted candles).
- This apparatus may contain lead and mercury. Dispose according to local, State or Federal laws. For disposal or recycling information, please contact your local authorities.
- Do not place this apparatus on the furniture that is capable of being tilted by a child and an adult leaning, pulling, standing or climbing on it. A falling apparatus can cause serious injury or even death.

- This apparatus should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided. Make sure to leave a space of 7.8 inches (20cm) or more around this apparatus.
- Added weight of the device may cause instability of a free-standing portable luminaire.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- Caution! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with FCC & Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC Statement

- Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
- Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Class II equipment symbol



This symbol indicates that the unit has a double insulation system.



This 'bolt of lightning' indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.



The 'exclamation point' calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.

FCC, IC and CE Radiation Exposure Statement for Mobile Devices

This equipment complies with FCC, IC and CE radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 7-7/8 ” (200 mm) between the radiator and your body. The transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

Déclaration FCC, IC et CE d'exposition aux rayonnements pour les appareils mobiles

Cet équipement est conforme aux limites FCC, IC et CE d'exposition aux rayonnements stipulées pour un environnement non contrôlé. Il doit être installé et utilisé en laissant une distance minimale de 7-7/8 ” (200 mm) entre le radiateur et votre corps. L'émetteur ne doit pas être placé au même emplacement que celui d'une autre antenne ou d'un autre émetteur, et ne doit pas fonctionner en même temps que de tels dispositifs.