

User manual

Model: RWC700

15W Wireless Charging pad

Please read these instructions carefully before charging and using this product, and keep this booklet for future reference.

Product Overview

This Wireless Charger is compatible with most smartphones that support the wireless charging function.

- 1.Place appliance on hard, level surface. Plug the USB-C connector into a USB-C port on your AC adapter(not included).
- 2.Place your phone in the centre of the charging base. The magnet holds the phone in place. Charging starts automatically.
3. The phone can be simply picked up off the charging base at any time..



Product specifications

Input voltage	DC5V/3 A;9V/2.22 A
Output power	max.15W
Efficiency	75%
Wireless charging reach	4 mm
Supported fast charging standards	PD 2.0/PD 3.0(input)/Qi 2(output)
USB-C cable length	1m
Dimensions	59×10 mm
Weight	80 g

Features

- 15W Wireless charging.
- With durable braided cable
- Premium aluminum housing for USB C connector

Safety Information

- * Check your phone's compatibility with the specifications indicated on this product before use.
- * This product is not a toy. It may contain small components. Keep out of reach of children.
- * Do not use the product to charge devices that require a charging current greater than that specified in the technical specification. Once your device is fully charged, disconnect it from the product.
- * Unplug the product from power sources when not in use.
- * Only use the product for its intended purpose.
- * Do not place the product on surfaces covered with cloth,tablecloth,etc. Do not place the product on heat-sensitive surfaces, as it may heat up during use.
- * Do not cover the product during use. Provide adequate clearance around the product.
- * Improper use carries risk of fire, explosion and other hazards.
- * Do not use or leave the product in dusty or otherwise contaminated environments.
- * Do not expose the product to extreme temperatures, direct sunlight, heat sources,etc.
- * Avoid contact with open flame. Do not place open flame sources, such as lit candles, on the product. Keep the product in a dry environment.
- * Do not expose the product to dripping or splashing water. Do not place water containers, such as vases, on the product.
- * Do not place heavy objects on the product. Do not subject it to shocks, falls or other mechanical damage.
- * Route the power cable so that it does not hang over the edge of a table, does not touch sharp objects or come into contact with heat sources, cannot be tripped over, etc.
- * Do not disassemble the product. Attempting to modify the product may damage it and result in serious injury.
- * Do not use the product if it appears damaged or emits an unusual odour.
- * Use only a soft,clean,dry cloth to clean the surface. Do not use harsh or chemical cleaners, petrol, thinners,etc.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.