


Internal view of the unit,
Rear cover removed




Internal view of the unit

Removing PLL module from Main P.W.Board




Internal view of the unit

Opposite side of PLL module & Main P.W.Board



Internal view of the unit

Control Board, Shield cover removed



Internal view of the unit
Opposite side of Control Board

