

ADDENDUM

Operating In Tablet Mode

FCC RF Exposure Warning: In Tablet Mode, the computer can be operated in wireless transmitter mode of operation. User must use X-Strap to assure that minimum 1.5cm spacing is provided between person's body and internal antenna(s) located on the side edges of LCD. Refer to safety instructions on page 3 of the Operating Instructions for details.

CF-18 X-Strap Installation Instructions




1. Begin installation by removing screws from corners of you Toughbook 18.



3. Place the attachment brackets over the screw holes from step 1. Screw onto machine with screws provided in X-Strap kit.



5. While not in use, carry the machine at your side using the removable shoulder strap.



2. Position the strap on the base of the Toughbook 18. Make sure that the clips are towards the front of the machine to allow quick and easy desk use.

4. Now you are ready to use your CF-18 X-Strap. While using, slide hand between strap and machine for a comfortable, safe grip.



Please hold the CF-18 as instructed. Please do not put the palm of your hand on the bottom of the machine. Your palm slips easily, if the CF-18 turns over you could injure your hand or arm.