

SCHEMATIC DIAGRAM MODEL NN-S980

SCHEMATIC DIAGRAM

NOTE: Door is closed.

Unit is not operated.

Ground

Chassis

CAUTION:
HIGH VOLTAGE AREA