


Feature Diagram

Before Operation

Ceramic Tray

1. Do not operate the oven without the Roller Ring and Ceramic Tray in place.
2. Only use Ceramic Tray specifically designed for this oven. Do not substitute any other Ceramic Tray.
3. If Ceramic Tray is hot, allow to cool before cleaning or placing in water.
4. Do not cook directly on Ceramic Tray unless otherwise indicated. Always place food in a microwave-safe dish, or on a rack set in a microwave-safe dish.
5. Ceramic Tray can rotate in either direction.
6. If food or utensil on Ceramic Tray touches the oven walls, causing the tray to stop moving, the tray will automatically rotate in the opposite direction. This is normal.




Cooking Modes: Heating Source


The diagram below shows examples of the accessories.

Use of these accessories may vary depending on the recipe/dish used. Further information can be found in the Cookbook.


Microwave




Bake



Broil



Combination



Microwave ←-----

Heater ←-----