


R704	
C703-C704	
C708-C710	
Q702	
J719	

ChipJPR J701
5mmJPR J711-J718, J720-J726, R729
10mmJPR J731-J737
15mmJPR J741-J742

R701-R703, R705-R757
C701, C702, C705-C707, C711-C738
D701-D709
Q701, Q703-Q706
ZD701-ZD703


: 1%



A606Y6G0


Oct 21, 2003
Inverter
Schematics diagram

4 SCHEMATIC DIAGRAM (FOR USA)





WIRING DIAGRAM

NOTE: When replacing, check the lead wire colour as shown.
Colours shown by () indicate colours of lead wire connector housing.



6 SCHEMATIC DIAGRAM





	AP/CP
SW1	POPCORN
SW2	POWER
SW3	SENSOR REHEAT
SW4	BROIL
SW5	BAKE
SW6	COMBINATION
SW7	AUTO CONVECTION
SW8	SENSOR COOK
SW9	MORE/RESS
SW10	CLOCK
SW11	QUICK MIN
SW12	KEEP WARM
SW13	WEIGHT DEF
SW14	TIMER
SW15	STOP/RESET
SW16	START

P.C.B.FU No.	JPR1	P.C.B.DU No.
A605Q6E00AP	OPEN	A603Y6E0CAP
A605Q6E00CP	BI-CRT	A603Y6E0OAP