




Photo 10.2 Display Unit Top View
(cover removed)
(showing CRT)




Photo 10.3 Front Bottom View of Display Unit
(base opened)




Photo 10.4 Front Bottom View of Display Unit
(base opened)
(showing INT (03P9252), GC (64P1106) & MB (03P9251) boards)



Photo 10.5 Rear Bottom View of Display Unit
(base opened)




Photo 10.6 Rear Bottom View of Display Unit
(base opened)
(showing PTU (03P9245) and Noise Filter box)




Photo 10.7 Power Supply Unit (PSU-001) Inside View
(cover removed)
(showing TX-HV and Power supply modules,
Power Transformer and Terminal boards)




Photo 10.8 Power Supply Unit (PSU-004) Inside View
(cover removed)




Photo 10.9 Scanner Unit (RSB-0051) Inside View
(cover removed)
(showing MIC, IF AMP. and Terminal boards)




Photo 10.10 Scanner Unit Inside View
(cover removed)
(showing RF Module and Magnetron)




Photo 10.11 Scanner Unit Inside View
(cover and RF Module removed)
(showing Scanner Motor, Gear-box and Magnetron)




Photo 10.12 RF Module Inside View
(showing Pulse Transformer, MD (03P6668) and PFN (03P6669) boards)