




Photo 10.9 Radar Antenna Unit Inside View




Photo 10.10 Radar Antenna Unit Inside View




Photo 10.11 Radar Antenna Unit Inside View
(shielded-cover removed)
(showing MIC, IF Board and INT Board)




Photo 10.12 Radar Antenna Unit Inside View
(shielded-cover removed)
(showing MD Board (03P9270) and Magnetron)




Photo 10.3 Display Unit Inside View
(cover opened)
(showing PNL board (PNL9194))




Photo 10.4 Display Unit Inside View
(cover opened)
(showing LCD)




Photo 10.5 Display Unit Rear View
(cover opened)




Photo 10.6 PCB (03P9268)

(cover removed)

(shielded-cover removed)