

AH-41 ADJUSTMENT

ADJUSTMENT		CONDITION	OPERATION	ADJUSTMENT ITEM	VALUE
-Adjust- Idling current	1	• TX unit only • 50Ω termination	• Apply 28V DC to TX unit only • Adjust idling current	TX Unit R120	80mA
-Adjust- Output power	2	• 50Ω termination • with BC-253/OPC-2461/OPC-2462	• Apply 13.8V DC to BC-253 • Input 1621 MHz/+23.3dBm signal to Tx Unit • Adjust output power	TX Unit R120	32.5 dBm

BC-253 is no adjustment.