

Brief Description for Cereuit Function

PWB Functions

(1)DL-71 PWB

DL-71 board is the key switch/digital main board.

This board has CPU , memories and peripheral curcuits.

(2)AN-17 PWB

AN-17 board is for battery charge control and detects voltage of the battery and also makes necessary voltages.

(3)PS-577 PWB

PS-577 board is the battery terminal board.

This board is connected with AN-17 board.

(4)LC-39 PWB

LC-39 board is the LCD terminal board. It also controls the backlight-LEDs of the LCD , and has the backup battery.

(5)AT-129 PWB

AT-129 board is the antenna board. This board has loop antenna and the driver circuit of it. It includes the Memory-Stick connector and RAM.